# SAMSUNG

How-To: Configure a **Samsung Device** as **dedicated Hotspot**

Knox Configure

Device Setup Procedure

ProKiosk Mode
Ver: 1.0
2020.03.30

Prerequisites

New Devices

Devices **must** be either **new** out-of-the-box, or have been **Factory Reset**, prior to following this guide. Devices that already display the Home Screen, need to be Factory Reset to restart the Setup Wizard.

Profile Setup and Assignment

Prior to powering on the devices, make sure they have been uploaded and assigned a Profile in Knox Configure. Please refer to the document:
How-To: Configure a Samsung Device as dedicated Hotspot – Admin Console Guide

Device Setup

Checking for updates...

Updating...

Updating Knox Enrollment Service...20%

Checking details...

This may take a few minutes.

SAMSUNG

Authenticating your information...0%

SAMSUNG

Authenticating your information...50%

SAMSUNG

Getting ready...100%

verizon✓

Hotspot DEVICE

Swipe the screen to start

4:03

< Mobile Hotspot

Off

Turn your phone into a Wi-Fi access point. Up to 8 other devices will be able to use your phone's mobile data to access the internet.

Samsung Galaxy A10e 6602
Allow all devices to connect.

Password

Wi-Fi sharing

6:31

First time Mobile Hotspot configuration

Samsung Galaxy A10e 6602

✓ Broadcast network name (SSID)

Security
WPA2 PSK ▼

Password
samsungs20ultra

Cancel   Save

<mark>Assign a password for the first time.</mark>

1	2	3	4	5	6	7	8	9	0
q	w	e	r	t	y	u	i	o	p
a	s	d	f	g	h	j	k	l
z	x	c	v	b	n	m

!#1 ,   English (US)   .   Done

6:32

Help

USB tethering

Use USB tethering to share your device's mobile network connection with a single computer via a USB cable. To turn on USB tethering, you must have the Smartphone Mobile Hotspot service added to your payment plan. To tether your device, connect it to a computer via a USB cable. Then, on your mobile device go to Settings > Connections > Mobile Hotspot and Tethering, and select USB tethering. USB tethering works with Windows and Linux. For more information, including how to use USB tethering with other operating systems, go to http://www.android.com/tether. For Windows XP, you may have to install a USB driver on your computer before you can tether your device. To install the drivers, go to http://www.samsung.com/support/. When you connect your device to a computer via a USB cable, you can either share your mobile network connection by tethering or you can share files. You cannot do both. Do not enable USB tethering if you want to access your device's SD card using your computer.

Mobile Hotspot

Turn your device into a Mobile Hotspot so you can share your mobile data connection with other devices. To turn on Mobile Hotspot, you must have the

OK

6:32

< Mobile Hotspot and Tethering

Mobile Hotspot
On

USB tethering
USB not connected