

FACILITY NAME

QUALITY ASSURANCE MANUAL

DATE

FACILITY ADDRESS

1.0 INTRODUCTION

1.1 Purpose and Scope

This manual details the quality assurance program in effect at Facility Name. It is meant to be a teaching tool and source of information for laboratory personnel. The Manual is based on Good Laboratory Practices, technical knowledge, industry-accepted standard analytical practices and common sense.

The Manual must be read and understood by all laboratory personnel as part of their training program. The Manual should also be referred to regularly as a source of information. A system of continuous updating is built into the Manual to allow it to change as laboratory conditions change or as new regulations are promulgated. *Terms, definitions and acronyms used throughout this manual can be found as Attachment 1.*

Whenever a technician or analyst is in doubt as to proper procedures in a specific circumstance, the Manual should be consulted. Omissions or errors should be immediately reported to the person responsible for maintaining this manual. **IT IS THE RESPONSIBILITY OF EACH LABORATORY WORKER TO ENSURE THAT THE PROVISIONS OF THIS MANUAL ARE FOLLOWED.** Disagreement with specific requirements or knowledge of changes causing deviation from the procedures should be discussed with the immediate supervisor before further work is completed. Laboratory personnel are encouraged to comment on the Manual and make recommendations for more efficient procedures.

The latest revision of the Manual is the applicable rule. *Check the MEDEP website for any future revisions.*

1.2 Quality Assurance Objectives

Facility Name is committed to the philosophy that quality operations result from quality planning, design, and work performance by skilled operational personnel. Facility Name's policy is to perform its varied types of technical work in accordance with standard quality assurance practices such as those put forth in the Good Laboratory Practices (GLP), various EPA guidance documents, and Standard Methods. A designated staff member should be responsible for all aspects of the quality assurance program including maintenance of standard operating procedures, laboratory audits, proficiency tests, and quality assurance training documentation.

Objectives of the quality program are:

- to provide representative data of documented quality to regulators
- to promptly identify variances and implement corrective actions
- to maintain readily identifiable and retrievable records that provide documentary evidence of the quality of activities performed
- to maximize the number of valid results by:
 - selecting the appropriate methodology

- by performing sufficient QC samples to document control
- by documenting all aspects of the analytical system
- by adhering to designated holding times
- to ensure that samples collected and tested are representative of the sampled environment through selection of:
 - appropriate sampling protocols
 - proper sample handling procedures
 - appropriate selection of holding times and analytical procedures
 - proper sample preservation
 - prompt extraction and analysis
- to optimize accuracy and precision data through the use of analytical procedures that minimize biases by using:
 - standard procedures
 - traceable standards
 - by calibrating analytical equipment within established acceptance limits
 - by implementing corrective action when measured accuracy and precision exceed pre-established limits
- to maintain traceability so that documentation explicitly describes the history of each sample from collection to analysis

2.0 MONITORING PROGRAM & PERMIT REQUIREMENTS

A wastewater treatment facility laboratory may analyze samples for both compliance with requirements specified by the plant's wastewater permit or for process control. The requirements of a plant's permit vary with the plant's processes and with the classification of the waterway that is affected. No matter which tests are specified, all permittees are required to comply with the regulations set forth in 40 CFR, Part 136 with regard to test methods used. You are responsible to ensure compliance with updates to the 40 CFR, Part 136. Refer to: <http://ecfr.gpoaccess.gov>.

A tabular format listing the permit required tests, the sample location, the sample type, and the monitoring frequency should be included. *Refer to an example in Attachment 2.* In addition, A tabular format listing process control monitoring tests, the sample locations, the sample types, and the monitoring frequencies should also be included. Refer to an example in Attachment 2.

Typically, a Discharge Monitoring Report (DMR) Form (DEP 49 Form) will have to be completed monthly in accordance with the Maine Pollutant Discharge Elimination System (MEPDES) Permit Program Instructions. The 49 form (*refer to an example in Attachment 3*) is completed from the laboratory bench sheets. The forms are preprinted and coded to include all of the effluent parameters as required by the permit.

3.0 ORGANIZATION, PERSONNEL, & TRAINING

It is important for efficient laboratory operation that all persons responsible for laboratory activities from sampling to preparation and signing of the Discharge Monitoring Report understand the operational structure and specific responsibilities within the organization.

3.1 Laboratory Organization

Include a listing of all individuals involved in laboratory activities ranging from the technicians, assistant operators, Chief Operator, Superintendent and Town Manager. Also include an organizational chart. *Example organization charts are included as Attachment 4.*

3.2 Responsibilities

It is the individual responsibility of all facility staff involved in lab work to perform their assigned tasks according to this QA Manual and to applicable SOPs. This includes responsibility for performing quality control analyses as specified in the method SOP and for entering the QC data in the appropriate logbook, electronic database, or method control file system.

In a well-staffed facility the Superintendent and QA Officer may have the following responsibilities. In a facility with only a few employees, this manual should state who is responsible for the following. **For the purposes of this document we are using the term superintendent which may be customized for your facility. Refer to definitions in Attachment 1.*

The Superintendent shall assure that analysts and technicians are instructed in the requirements of the Laboratory QA Manual and SOPs for the analytical method or other procedure. The Superintendent shall review sample QC data to assure that QC analyses are being performed at the required frequency, that data are documented in the appropriate logbook, electronic database, and that established corrective action procedures for out-of-control situations are followed and the results documented. It is the responsibility of the Superintendent to assure that data have been validated and reported to the appropriate person.

The Quality Assurance Officer (QAO), or designated person (Superintendent), shall be responsible for conducting systems audits and inspections for compliance with this manual and laboratory SOPs. This person shall be responsible for maintaining historical files of all QA documents, reviewing QC charts, documenting findings and corrective actions, reviewing training records, managing PTs, maintaining conformance with certification requirements and reporting findings related to all of the above to the Town Manager.

3.3 Training

Appropriately and adequately trained staff is one of the most important elements necessary to meet data quality objectives. An appropriately trained analyst has achieved an acceptable level of skills and understanding, sufficient to generate data of documented and acceptable precision and accuracy as defined in the applicable method. A trained employee is able to competently carry out the defined duties of his/her job. Competence is

based on adequate and sound educational background, specific training to perform assigned duties, and experience in the use of techniques and methodologies employed. A trained employee is able to apply a method and/or technique with sound judgement, demonstrate effective problem solving, perform at an acceptable level of independence, and meet or exceed minimum standards for productivity and data quality. A trained employee understands the basic principles of quality control and quality assurance and their application to the task at hand.

A form should be used to document technical training for each analytical method (*Refer to an example in Attachment 5*).

Training shall be conducted in a two-fold manner.

- First, the trainer demonstrates the procedure to the employee.
- Second, the employee conducts the procedure while the trainer observes and discusses the procedure with the employee.
- A training form should be completed for each procedure in which the analyst is being trained.

It is recommended that Initial Demonstration of Proficiency (IDP) and Continued Demonstration of Proficiency (CDP) be documented annually within each employee's training files. This can best be accomplished by the analysis of four known spikes (LCSs) prepared by the analyst, or by the analysis of a known spike (PT or DMR-QA) obtained from an outside source. The recoveries of these spikes must meet the acceptance limits described in the method or SOP.

4.0 QA MANUAL & STANDARD OPERATING PROCEDURES

4.1 QA Manual

This document describes policies related to operation of the analytical laboratories. It provides overall guidance regarding acceptable practices and discusses each element of the Quality Assurance Program. Adherence to the practices described in this manual is required of all employees. This manual may be revised with the written authority of the Superintendent.

4.2 Standard Operating Procedures Manuals

A written SOP manual must contain procedures related to:

- sample collection
- storage
- preparation
- analysis
- disposal
- data validation
- data reporting
- employee training and safety

Each SOP within the manual should contain:

- numbered sections structured in a step-wise manner
- a description of all record-keeping requirements for each step in the SOP
- examples of forms used included as tables or figures and referenced within the text

A designated person shall keep an inventory of SOP numbers, implementation dates and review dates.

For appropriate examples refer to the Maine Wastewater Control Association (MWWCA) SOPs. Be aware that these are under constant revision. *Please refer to the MWWCA website for updates: www.mwwca.org.* Each Standard Operating Procedure shall contain at a minimum, the following information:

Title - The name of the concerned task

SOP Number - The internal document control number assigned and tracked by the QA Department

Acceptance - The signature of the originator(s), Quality Assurance Officer and appropriate operations management authority to officially adopt the procedure

Date - Date of issue of most recent revision

Scope and Application - An explanation of the objectives of the procedure, typical applications and limitations

Responsibilities - Identification of the individuals (by title or organizational position) and their responsibilities in performing and facilitating the tasks governed by the SOP

Summary of Method - A short synopsis of the chemistry involved in the procedure.

Interferences - Any factors that may interfere with the proper performance and/or outcome of a procedure and that could compromise the results.

Apparatus and Materials - A complete list of the equipment, apparatus, etc. needed for the procedure

Reagents - A complete list of the reagents, standard solutions, solvents, etc. needed for the performance of this procedure

Sample Collection, Preservation and Handling - Any special considerations needed to assure the integrity of the sample and, consequently, the analytical process.

Method/Procedure - A clear description of the task on a step-by-step basis. The method description should be written clearly enough, and in sufficient detail, to ensure that any two persons performing the procedure will achieve equivalent results. Acceptable and equivalent alternatives should be addressed whenever possible, and described in the same detail. Where applicable to the SOP, the procedure should include a discussion of sample preparation and calibration requirements and also a summary of the automated and manual calculations performed as well as reporting requirements, including data flow charts as appropriate. The SOP should address differences between a published method and the facility's performance of that method, if any exist.

Quality Control Requirements and Acceptance Criteria and Corrective Actions - An outline of quality control requirements, including, procedures, frequency requirements, and acceptance criteria. Corrective actions include a description of what must be done, when and by whom in instances when the QC requirements are not met. This section may be in the form of a table.

Applicable Documents/References - A listing of pertinent, supporting procedure or reference documents such as methods, manuals and/or SOPs

5.0 FACILITIES & GENERAL LABORATORY SAFETY

5.1 General Information

Describe the physical layout of the facility and where the laboratory is located. Provide a floor plan of the facility.

5.2 Laboratory Safety

It is Facility Name's goal to maintain a safe and healthful work environment. Sample receiving areas and laboratories shall be equipped with suitable hoods, respirators, protective clothing and eye wear, gloves and/or other measures to prevent or minimize staff contact with hazardous substances. Safety equipment such as eyewash stations, drench showers, fire blankets, spill adsorbents and neutralizers, fire extinguishers, and first aid materials shall be available.

A designated individual at the facility should oversee Environmental Health & Safety aspects. For larger facilities, a safety committee may be formed. The Safety Committee shall meet on a regular basis to discuss any new safety or health related issues in the laboratory. The Safety Committee, or designated person, shall:

- help to prepare and maintain safety-related SOPs
- conduct an orientation session with each new staff member to familiarize him/her with routine and emergency safety procedures and equipment
- conduct a tour of the laboratory

During the tour the following will be discussed or demonstrated:

- needs for eye, skin, and respiratory protection
- the use of safety glasses, face shields, goggles, partial and full-face respirators which will be issued after respiratory protection training
- the use of ventilated work areas, fume hoods, gloves and Tyvek coveralls
- the location and use of eye wash stations, drench showers, fire extinguishers, and first aid equipment
- requirements for fire and spill notification, emergency procedures, and evacuation

Employees shall be responsible for their own safety. Managers may require that certain levels of protective equipment be worn, when in their judgment, it is appropriate. All applicable standards of the Maine Department of Labor shall apply for municipal facilities and the Occupational Health & Safety Administration for commercial facilities.

The following are basic safety tips to follow when working in a laboratory area:

- 5.2.1 Always use proper safety goggles or a face shield when performing any test where there is potential danger to the eyes.
- 5.2.2 Use care when making rubber-to-glass connections. Gloves should be worn when making such connections to prevent injury in the case of breakage. Use a lubricant such as water or glycerin, but never grease or oil. Never force the

rubber stopper into the glass tubing. Hold the glass tubing as close to the end being inserted as possible to prevent breaking.

- 5.2.3 Always check labels on bottles carefully to make sure that the proper chemical is being selected. Keep storage areas clean and organized. Never store incompatible chemicals together, i.e. acids and bases or oxidizers and flammables.
- 5.2.4 Never handle chemicals with bare hands. Always wear appropriate gloves when handling dry chemicals.
- 5.2.5 Always work in a fume hood with appropriate ventilation when using chemicals or samples with toxic fumes.
- 5.2.6 Never take food or drinks into the laboratory area or chemicals or samples into areas designated for eating.
- 5.2.7 Use care when handling hot equipment or glassware.
- 5.2.8 Never smoke in the laboratory area.
- 5.2.9 Never pipette by mouth. Always use appropriate pipettes and bulbs.
- 5.2.10 Always be aware of the relevant safety information on the chemicals and reagents used in your work area. The Material Safety Data Sheets (MSDS) provide information concerning the safe handling of chemicals, their storage, hazards, first aid and disposal. An MSDS should be available from the manufacturer for every chemical used in the laboratory. These should be easily accessible to all employees.
- 5.2.11 Do not use damaged or broken glassware. These should be disposed of in a separate container for broken glassware.
- 5.2.12 Always add acid to water first unless the procedure specifically requires the reverse. If water must be added to an acid or a base first, do so very slowly in a fume hood, stirring the solution as the water is added. Note that this reaction may produce significant heat.
- 5.2.13 Always wear appropriate personal protective equipment (PPE) such as a lab coat, goggles, safety glasses, gloves, etc.
- 5.2.14 Be sure that an eyewash station and a shower are available in case of a chemical spill. Immediately rinse affected area with large amounts of water.
- 5.2.15 Be sure that personnel are trained in the use of fire extinguishers.

5.3 Security

Provide a description of the facility's security system and access to the facility by employees and visitors.

6.0 MATERIALS, APPARATUS & EQUIPMENT

A wastewater laboratory must have all of the necessary equipment to perform the required tests, to prepare the required solutions and standards and to perform the required quality control samples. Evaluation and selection of suppliers and vendors is done primarily on the basis of the quality of their products, their ability to meet the demand for their products on a continuous and short term basis, the overall quality of their services, their past history, and competitive pricing. This is accomplished through evaluation of supporting documentation provided by the vendor such as certificates of analysis and recommendations. All consumables and equipment must be reviewed to assure that they conform to the specified quality requirements of the methods.

6.1 Stock Standards, Reagents, Solvents & Media

6.1.1 Selecting a Grade

To ensure that all chemical standards, reagents, solvents, and media conform to specified quality requirements, only reputable chemical suppliers are used in the laboratory. When in doubt, most standards, reagents, solvents, and media come with specifications concerning their purity. These specifications should be checked to verify that the purity of the standards, reagents, solvents, or media meets the needs of the particular method. The manufacturers can also be contacted to determine if there are specifications for the analytes of interest.

6.1.2 Inspection & Documenting Date of Receipt

Upon receipt, chemical standards, reagents, solvents, and media are checked for possible damage incurred during shipment. If the standards, reagents, solvents, and media are found to be intact, the bottles are then labeled with the date of receipt and the letters "DR" to indicate "date of receipt." The purpose of documenting date of receipt on the bottles/cartons is to facilitate rotation of the laboratory inventory so that the oldest (first received) products are utilized first.

6.1.3 Documenting Expiration Date

The expiration date listed on the standard, reagent, solvent, or media container label should be noted and circled. If no expiration date appears on the label, it is recommended that an expiration date of 5 years for reagents and one year for standards from the date of receipt be assigned. The bottle is then labeled with the assigned expiration date and the letters "EXP" to indicate "date of expiration." This assigned date shall be the effective expiration date unless it is shown through analysis that the standard, reagent, solvent, or media has degraded or become contaminated. The material must be discarded if this is the case.

The purpose of documenting date of expiration on the container is to prevent the use of chemical standards, reagents, solvents, or media that have exceeded their practical shelf life. Some methods may require shorter expiration dates or restandardization to verify the concentration and/or purity.

6.1.4 Storage

Chemical standards, reagents, solvents, or media labeled with the dates of receipt and expiration are then stored in the assigned storage location in the appropriate laboratory area. Commercially prepared standards, reagents, solvents, and media

must always be stored according to the manufacturer's directions. Some materials may require refrigeration or freezing. Those that are sensitive to the light should be stored in dark bottles and in a cool, dark place. Be sure not to store incompatible chemicals together.

6.1.5 Documenting Date Opened

When a new (unopened) standard, reagent, solvent, or media is needed for use in the laboratory the oldest (first received) bottle is opened. The chemist who opens the bottle immediately labels it with the date opened and the letters "DO" to indicate, "Date opened."

6.1.6 Traceability

Whenever a chemical standard, reagent, solvent, or media is used for an analysis, the manufacturer's lot number must be recorded on the raw data or appropriate logbook page. This is required to ensure the traceability of the reagents, solvents, and media used for an analysis. This is especially important as a corrective action tool when contamination of a reagent, solvent, or media is suspected.

6.1.7 When the practical shelf life of a chemical standard, reagent or solvent has expired the material is disposed of in accordance with the appropriate disposal procedures.

6.1.8 Preparation and Dilution

If a preparation or dilution of a chemical standard, reagent, solvent, or media is required, a similar documentation procedure to that listed above shall be used. Instead of recording the date received, the date prepared shall be recorded with the preparer's initials. A date of expiration shall be assigned keeping in mind the expiration date of the native reagent or solvent. The expiration date of the solution or dilution shall not exceed that of the native reagent or solvent. The expiration date assigned to dilutions shall be no more than one year, depending on the analysis. Please refer to individual method SOPs for more detail on reagent and solvent shelf lives. In addition, the stock manufacturers' lot numbers must be recorded on the container.

6.1.9 Lot Numbers

As with stock reagents/solvents/media, the lot numbers of all dilutions and solutions should be recorded on the raw data or appropriate logbook page.

6.1.10 In addition to labeling of bottles, receipt and preparation activities should be recorded in a logbook. This will help to maintain traceability and to ensure that standards, reagents, solvents and media are always prepared consistently. *Refer to an example label, standard documentation requirements and a sample logbook page in Attachment 6.*

6.2 Laboratory Equipment

6.2.1 Refrigerator/Freezer Temperature Logs

Refrigerators and freezers used for sample and materials storage are checked every weekday to ensure that they are operating properly and within established temperature ranges. Refer to section 6.6.2 for thermometer information. All

information is recorded in logbooks or on benchsheets *Refer to an example in Attachment 7*. Routine maintenance such as defrosting is performed as needed.

6.2.2 Incubators

Incubators are required for the Biochemical Oxygen Demand (BOD) test and for coliform testing. Incubators must be capable of maintaining the required temperature. The temperature must be monitored every day of use to ensure that they are operating properly and within established temperature ranges. Refer to section 6.6.2 for thermometer information. All information is recorded in logbooks or on benchsheets.

6.2.3 Desiccators

Desiccators are containers that are used to provide a moisture-free environment to cool objects and chemicals. Desiccators are used in gravimetric tests to prevent samples from trapping moisture. The container must have an airtight seal. The bottom section of the desiccator contains a chemical, or desiccant that absorbs moisture from the air. The desiccant should be color changing so that when it no longer can absorb moisture, the color will change. At this time, the desiccant must be replaced with a fresh supply. To save money, a plastic storage container with a tight cover, may be used as a desiccator. A metal trivet can be placed inside to keep the contents from coming into contact with the desiccant.

6.3 Glassware

All glassware used in the laboratory must be maintained in good condition, cleaned, properly stored, and separated according to its specific laboratory application. Cracked, excessively chipped or otherwise defective glassware must be discarded or repaired. All method references give example types of glassware to use. All volumetric glassware utilized shall be sufficient to meet the quality control requirements of the method, i.e. to meet the precision and accuracy of the method.

6.4 Glassware Cleaning

Labware (e.g., glass beakers, plastic test tubes, Teflon stirring bars) must be thoroughly and scrupulously cleaned prior to utilization as part of producing analytical data of consistently high quality. In general, after each use, glassware should be washed with soap and water, rinsed with tap water and then rinsed with reagent grade or deionized water. Glassware should be allowed to dry and stored on clean areas as free from dust as possible. Specific glassware procedures depend on the analysis to be performed. Glassware used for the total phosphorus test must be cleaned with non-phosphate detergent and acid rinsed. BOD glassware may be soaked in a bleach solution after cleaning and then rinsed to eliminate any bacterial contamination. These specific procedures should be included in the specific method SOPs.

6.5 Sample Containers

Samples should be collected in containers as specified by the SOPs. Ideally, all sample containers should be purchased pre-cleaned from a reputable commercial source. In some cases pre-cleaned containers are received with certificates of analysis

documenting the concentration levels of applicable analytes for each container type and lot. Certificates of analysis accompanying container lots should be maintained by the laboratory. Alternatively, sample bottles may be re-used if appropriately cleaned.

6.6 Instruments

Laboratory instrumentation used shall be as specified in the protocol for the analytical method. A master list of the major analytical instrumentation currently in use in by the facility should be maintained.

Preventive maintenance is performed for each instrument by manufacturers, analysts and field service technicians on an ongoing basis and the activities documented in a bound instrument maintenance logbook or in the instrument runlogs.

Corrective maintenance shall be provided as required for all instruments and equipment and documented in appropriate logbooks. Factory replacement parts, trained service technicians and first quality materials shall be used whenever necessary.

6.6.1 Analytical Balances

Annually, calibration of the entire analytical range shall be checked by a qualified service technician. However, balance calibration must be verified each day of use. Working class weights are used for daily verification. These weights should also be verified against NIST Class I weights on an annual basis. An outside service may be used for this if the laboratory does not have NIST Class I weights available. *Refer to Attachment 8 for guidance on balance verification.*

6.6.2 Thermometers

Working thermometers are used in the lab to track storage temperatures and to perform methods at required temperatures. The type of thermometer used will be dependent on the method specifications. For example, E-coli samples are incubated at $44.5\text{ }^{\circ}\text{C} \pm 0.2\text{ }^{\circ}\text{C}$. A thermometer that is capable of accurately reading $\pm 0.2\text{ }^{\circ}\text{C}$ must be used. Vendor catalogs usually give a description of the accuracy of each thermometer. Mercury thermometers should be avoided, if possible, due to their hazardous nature. Alcohol or digital thermometers should be used instead.

Each working thermometer should be individually numbered and tagged with an identification number. All working thermometers should be compared with the reference thermometers on, at least, an annual basis. *Refer to Attachment 9 for guidance on thermometer verification.* In addition, working thermometers should be visually inspected by laboratory personnel prior to use. Calibration temperatures and acceptance criteria are based upon the working range of the thermometer and the accuracy required for its use.

Certified, or reference, thermometers are maintained for checking the calibration of working thermometers used during testing. Reference thermometers are provided with NIST traceability for initial calibration and should be recertified every five years, by an outside service, with equipment directly traceable to the NIST.

6.6.3 pH/Electrometers

These meters are calibrated using buffer solutions before use each day, and once after each four hours of use. *Refer to the MWWCA SOP or to Standard Methods for pH meter calibration.*

6.6.4 Spectrophotometers

During use, spectrophotometer performance is checked against initial calibration verification standards (ICVs) and continuing calibration verification standards (CCVs). The instrument operating capability and wavelength verification are also evaluated every year by an outside service.

6.6.5 Ovens

Oven temperatures may be monitored using a thermometer intended for oven monitoring that may be compared to a NIST traceable thermometer annually. Oven temperature must be checked every day of use and recorded in the appropriate analytical logbook.

6.7 Autoclave

The autoclave is used in the sterilization of equipment prior to bacteriological testing. The autoclave must be capable of developing and maintaining 15 psi at 121 °C for at least 20 minutes. Temperature must be recorded in an autoclave temperature log.

6.8 Pipettes

Pipettes are specially calibrated glass tubes used for accurately transferring small volumes of solution (usually less than 50 mL). Volumetric pipettes are designed for the accurate transfer of a specific amount of liquid. These pipettes have narrow tips with a bulb-like expansion in the middle. The calibration mark is found above the center expansion. These pipettes, typically indicated as Class A, are designed to free-flow until a small amount of liquid remains in the tip.

Measuring pipettes are graduated to deliver varying volumes. These are less accurate. An automatic pipette may be used to deliver varying volumes of liquid more accurately than a measuring pipette. However, these pipettes do require daily calibration if used. They should be inspected before use. All automatic adjustable pipettes must be calibrated each day of use at the maximum volume. If you are interested in checking the quality of pipettes, this may be done so by comparing the true weight of a delivered volume of reagent grade or DI water and weighing. Note that 1 mL of water = 1 gm of water. All recordings should be recorded in a logbook (*refer to an example in Attachment 10*).

6.9 Reagent Water or Deionized (DI) Water

The performance of analytical work requires that the water used for preparation of samples and reagent solutions, and final rinsing of glassware be "theoretically pure," i.e. free from interferences, electrolytes, and other contaminants. In all cases, unless specified by the analytical SOP, reagent grade or deionized water is used.

The following tests should be performed to document water quality. The results should be filed.

General Lab Water		
Parameter	Limit	Monitoring Frequency
Conductivity	<2 umhos/cm @ 25 °C	Monthly

Water for Microbiological Analyses		
Parameter	Limit	Monitoring Frequency
Conductivity	<2 umhos/cm @ 25 °C	Monthly
Total Residual Chlorine	<detection limit	Monthly
Heavy Metals (Cd, Cr, Cu, Ni, Pb, Zn)	<0.05 mg/L	Annually
Heterotrophic Plate Count	<500 CFU/ml	Monthly

7.0 BASIC LABORATORY SKILLS

In order for a laboratory test to produce accurate and representative results, it is critical for analysts to understand the importance of basic laboratory techniques such as measuring, diluting, weighing and calibrating.

7.1 Measuring

Deciding how to measure a volume of liquid depends on several factors – the type of liquid, the amount of liquid and how accurate the measurement has to be. Thick liquids are usually measured best using wide mouth glassware. The larger the volume of sample measured, the less accurate that it needs to be. Typically beakers and flasks are used for measuring larger volumes of liquid and are less accurate. Burettes and pipettes are used for measuring smaller volumes of liquids and are more accurate. Measuring devices will either be “TC” (to contain) or “TD” (to deliver).

“TC” glassware is calibrated so that when it is filled to the calibration mark or a certain graduation mark, the liquid column will contain a specific volume of liquid. In dispensing this specific volume, the entire contents of the column must be transferred. A full volume “TC” pipette may require that you “blow out” the last drops of liquid, using a pipette bulb, to deliver the measured volume.

“TD” glassware is calibrated so that when it is filled to the calibration mark or a certain graduation mark, the volume indicated will be delivered upon dispensing the liquid. Full delivery “TD” pipettes calibrated from the zero mark to the pipette tip. After draining the pipette, a few drops of liquid may remain in the tip. This liquid is released by touching the tip of the pipette against the side of the transfer container until no more liquid drains out.

All measuring devices used for liquid volumes have a downward curve at the surface of the liquid. The curved surface is called the meniscus. All measurements taken should be made on the graduation closest to the lowest point of the meniscus. *Refer to Attachment 11 for example glassware and meniscus.*

7.1.1 Graduated Cylinders

Generally, graduated cylinders are less accurate and should only be used for measuring liquid volumes greater than 25 mL. Graduated cylinders should not be used to prepare standard solutions. To use a graduated cylinder, shake or stir the liquid to be transferred to be sure that any solids are mixed. Quickly transfer the liquid to the graduated cylinder before the solids have a chance to settle out. Measure to the meniscus at the graduation mark and then transfer the sample to its final container.

7.1.2 Pipettes

Pipettes are generally more accurate and can be used for liquid volumes less than 25 mL. The liquid should be drawn into the pipette using a pipette bulb, past the zero mark, drained back down to the zero mark, and then the desired volume of liquid drained into the test container. The liquid being transferred should be stirred or shaken to ensure a homogenous sample.

7.1.3 Burettes

Burettes are typically used for titrations in which an accurate volume of a titrant (known concentration) is dispensed into a known volume of sample (unknown concentration). As titrant is added, a chemical reaction is initiated and proceeds as more titrant is added to a recognizable endpoint (color change, meter reading). At this point, the titration is complete.

A burette is calibrated to be read from the top down. For example, a 25 mL burette will have the zero mark at the top and the 25 mL mark at the bottom, above the stopcock, with many graduations in between. The volume dispensed is read from the lowest point of the meniscus. It is always best to fill the burette past the zero mark and then to empty it so that the zero mark is at the bottom of the meniscus. The burette should be refilled if there are any air bubbles present.

The stopcock at the bottom of the burette is designed to control the flow of liquid. When the lever is horizontal, the stopcock is closed. It is fully open when it is vertical. The burette tip must not be used if it is damaged, cracked or dirty. Burettes should be acid cleaned periodically.

7.2 Weighing

The type of balance used will depend on the accuracy of the measurement needed. Depending on the required weight, the balance should always at least one decimal place further than that. For example, if a method says to weigh 5.2 grams, the balance used should be able to see out to 0.01 grams or better. Always refer to the manufacturer's instructions before operating a balance. Also, refer to section 6.0 for additional weighing information.

7.3 Dilutions

When performing analytical tests, it is often necessary to dilute, or to reduce the strength, of a sample or solution. A sample or solution can be diluted by adding a known amount of water to a known amount of the sample or solution. The amount of the dilution will depend on the original strength of the solution or sample and the desired final strength needed for the test.

When dilutions are performed, a dilution factor must be taken into account. The dilution factor is the final total volume divided by the volume of sample or solution used. The result obtained on a diluted sample must be multiplied by the dilution factor to obtain the correct final result.

Example: 20 mL of a sample is diluted with 80 mL of deionized water for a final volume of 100 mL.

$100 \text{ mL} / 20 \text{ mL} = 5$ (dilution factor)

The analytical result is 3.7.

$3.7 \times 5 = 18.5$ final result

When solutions or standards need to be diluted to obtain weaker strengths, the following equation should be used to determine how much to dilute.

$$(V_i)(C_i) = (V_f)(C_f)$$

Where: V_i = Initial volume of original solution/standard
 C_i = Initial concentration of original solution/standard
 V_f = Final desired volume of diluted solution/standard
 C_f = Final desired concentration of diluted solution/standard

Typically, C_i , V_f , and C_f are known values. The analyst needs to determine the original volume (V_i) of a known strength to be added to a specific volume of a desired strength.

The following rules apply when making dilutions:

- Samples that are over the calibration or working range of the instrument or analysis must be diluted and rerun.
- Such dilutions should be made to attempt to bring the sample concentration around the mid-point of the standardization.
- Sample dilutions should be performed using volumetric glassware (volumetric pipettes, burettes, or volumetric flasks), calibrated adjustable pipettes or, if available, instrument auto-samplers.
- Sample dilutions should be made so as to maximize the amount of native sample used. This will provide for a more representative portion of sample.
- If a large dilution is required it is better to do a serial dilution rather than using a non-representative aliquot of sample. (Example: A sample requires a 1/1000 dilution. Make a 1/100 dilution of the native sample and then a 1/10 dilution of the initial dilution).
- Dilution factors should be clearly marked on the raw data. It is preferred that the dilution factor is expressed in such a fashion that it may be recalculated, i.e. 1:10 or 1/10 is preferred over 10x.
- When possible, native samples should be poured out of their original containers into small sample cups, before making dilutions, so as not to contaminate the native sample.
- Used pipette tips or other measuring devices should never be inserted into original sample containers.

7.4 Analytical Calibration Procedures

Wet chemistry instruments are standardized for the parameter of interest by the analysis of a set of calibration standards prepared by diluting a stock solution of known concentration. A calibration curve within the working range of the instrument is established by analysis of one to five working standards, including a zero point.

Most instruments in the wastewater laboratory have a linear relationship between response and concentration. The linearity may vary at the high and low ends of the curve where detector saturation or insensitivity come into play. A calibration curve is

generated through linear regression with concentration as the x-axis and response as the y-axis. If the instrument is typically adjusted to read zero in the presence of a blank, then the zero point should be included in the linear regression. The calibration must reflect an acceptable correlation of data points or linearity to be acceptable. In cases where the calibration data are outside of these criteria, the analyst must rerun the calibration standards (meeting the same criteria), changing instrumental conditions as necessary until appropriate acceptance limits for the method are achieved. *Refer to Attachment 12 for example calibration curves.*

Calibration standards for each parameter are chosen to bracket the expected concentrations of those parameters in the sample, and to operate within the linear response range of the instrument. Sample concentrations that fall above calibration range are diluted and reanalyzed until they are within the calibration range. Calibration standards should be prepared as described in each method or SOP. At a minimum, each calibration should contain at least three standards and a blank. The reporting limit is verified by analysis of a standard at the reporting limit.

An independent standard is analyzed to confirm the calibration. If the calibration is not within acceptance limits, the instrument is recalibrated. The samples are analyzed for the analyte of interest. During sample analysis, a check standard (Continuing Calibration Verification, CCV) is analyzed to monitor instrument stability. If the CCV indicates that instrument calibration has changed by more than the method specified acceptance limits, the instrument is recalibrated and the analysis is repeated. Following completion of the sample analyses, the check standard is reanalyzed to confirm calibration. If calibration verified, the analysis is completed. However, if the calibration is not verified, appropriate corrective action is taken and effected samples are reanalyzed.

For some analyses that are performed frequently, and for which substantial calibration data are available, a complete recalibration is not required each time an analysis is performed. As long as one calibration standard (Initial Calibration Verification - ICV), analyzed at the beginning of the analysis, does not vary from the expected response (based on the most recent initial calibration curve) by no more than $\pm 25\%$ or as specified by the method, or SOP, whichever is more stringent. If this criterion is not met, a complete recalibration is necessary.

8.0 SAMPLING PROCEDURES

The value of any laboratory analysis performed on a treatment plant sample depends upon the overall quality of the sample on which the test is performed. The sample must be representative of actual conditions in the plant. Often, the error most commonly committed in analytical testing is that of improperly collecting or preserving samples.

The purpose of sample collection is to obtain a portion of the wastewater that is small enough to be conveniently handled in the laboratory and still be representative of the total waste stream. This portion is intended to simulate millions of gallons of flow in some cases. The sample must, therefore, reflect usual conditions for water passing that sample point throughout the day or testing period. The sample must be collected in such a manner that nothing is added or lost in the portion taken and no change occurs between the time the sample is collected and the laboratory test is performed. Determining the best location for the sample point is critical in providing an appropriate sample (i.e. a sample tap in a dead area of a reservoir or on the floor of a process basin serves little or no purpose in helping the plant operator determine water quality).

8.1 Sampling Techniques and Sample Types

There are two manners in which to take samples...manually and automatically. Manual sampling involves the use of dippers, sample thieves (or weighted bottles) and hand-operated pumps. Automatic sampler units or ISCO's use a computer controlled peristaltic pump to pull samples at regular intervals over a set period of time, thus characterizing flow over time.

Beyond the specifics of the sample matrix and types of compounds to be analyzed, the two classifications of samples that are collected are **Grab Samples** and **Composite Samples**.

8.1.1 Grab samples are samples collected over a period of time not to exceed 15 minutes and they reflect the source material conditions at a particular instant of time. Grab samples are used primarily for analyses that need to be run immediately after collection (i.e. dissolved oxygen, chlorine, pH), but also include those analyses that need the entire contents of a sample container (i.e. Bacteriological)

8.1.2 Composite samples are obtained by taking an appropriate number of grab samples collected at equal intervals or proportional to flow and serve to characterize the average conditions at a sample point over time. Flow proportional sampling takes into account changing sample flow from a volume standpoint. The nature of the composite sample requires that the tested parameters be stable in the composite container for the duration of the sampling, which is often 24 hours and typically involves refrigerating sample to 4° C.

8.2 Sample Containers, Sampling Equipment and Aliquot Size

Using the appropriate sample containers to store the samples prior to analysis is critical to the successful analysis of wastewater samples. The sample container should always be an inert material that will not contribute to or artificially effect the integrity of the sample. The two major choices available for sample storage are Glass and High Density Polyethylene (HDPE) with Teflon lined caps. A sample taken for metals analysis, for

example, is taken and kept in HDPE with the exception of mercury, which should be kept in a glass container since it is susceptible to diffusion through plastic. While the reuse of sampling containers can be an ecologically conscientious choice, this can open up avenues for cross contamination if the bottles are not cleaned properly. Sampling equipment, however, is typically reused and susceptible to the same contamination issues. Use a non-phosphate based detergent and a hot water rinse, acid washing, re-rinse, deionized or reagent grade water rinse and air dry process to ensure cleaning. Use an appropriate acid for the acid wash step (i.e. do not use nitric acid in bottles to be later used for nitrate analysis, or for a sample container to be used for chlorine analysis, do not use hydrochloric) The use of a bottle blank will help to verify the efficacy of the cleaning regiment for reused sample containers.

Allocating the correct sample volume is also a key part of the sampling process. There is a preferred sample size for all analyses that provides just enough sample to achieve low enough detection limits for each method, but not so much sample that then becomes an issue for the laboratory waste disposal.

8.3 Sample Preservation

To ensure representative samples, we do not want the sample characteristics to change during the sampling process, especially while collecting composite samples. Sample preservation is a way to slow down or prevent any change in the sample characteristics. The three processes which act upon samples while in the sample containers are Biological, Chemical, and Physical.

8.3.1 Biological processes result from the microbes that exist in wastewater naturally. As they multiply and grow, they utilize certain nutrients in the water and produce byproducts such as nitrate and acids that can alter the baseline results of the sample. If the sample is being tested for coliforms, the baseline plate counts will change drastically over time.

8.3.2 Chemical interactions are often complex interactions between the many components of wastewater. Often times, sulfides can interact with cyanide to form thiocyanate, removing both chemicals from solution. Nitrite can be oxidized by hexavalent chromium into nitrate changing both concentrations.

8.3.3 Physical processes can involve precipitation and loss of trace metals from solution and volatilization of dissolved gases from liquid and sludge samples.

For on site analysis at the plant, preservation is often not required since the samples are typically run right away, but for work being sent out to an outside lab, the preservation process must be done and done correctly.

8.4 Preservative Systems

The most common preservative steps are:

8.4.1 Cooling the sample to 4° C, which inhibits biological activity, and keeps dissolved gases in solution.

8.4.2 Sodium thiosulfate is used to remove chlorine while copper sulfate, and mercuric chloride is used to control biological growth.

8.4.3 Zinc acetate is used to trap sulfides.

8.4.4 Appropriate pH adjustment is also used frequently (using sodium hydroxide to adjust upwards to over 12 and using hydrochloric, sulfuric or nitric acid to adjust downwards to a pH of less than 2) The appropriate acid is required. You would not want to use nitric acid for a nitrate sample, and likewise, sulfuric acid in a sample being analyzed for sulfates. Acids are critical for keeping target analytes such as metals, in solution. Non-preserved samples must be run immediately.

8.5 Holding Times

There is no topic that is perhaps more critical to the successful operation of any laboratory, than running samples within the accepted holding time for each analysis. The holding time for analytes reflects the allowable time span permitted before the analysis must begin. Due to the sensitive nature or volatility of certain compounds, this permitted time frame within which an analysis must begin is critical to ensuring that target compounds have been verified within a certain margin of accuracy.

On site analysis at the plant is typically done within a few minutes to a few hours of sampling, making the issue of holding times less critical. However, for the work that is sent out for analysis, holding times become a much bigger issue. Analyses like temperature, pH, dissolved oxygen, and total residual chlorine all have an immediate testing requirement, and are either done in the field upon sampling or immediately after receipt in the laboratory. Analyses such as coliform / E. coli should be run within a 6 hour window to verify bacterial counts (which are forever changing as the ambient bacterial population continue to multiply, sometimes exponentially). A BOD analysis, optimally, should be run within 24 hours of sampling, although EPA has, in the past, allowed up to 48 hours for analysis to begin.

8.6 Documentation

All activities performed in the field should be documented in a field logbook and on a label to be placed on the sample containers. The documentation in the logbook should include:

- sampling techniques
- conditions such as time, flow rate, etc

The sample label should include:

- time and date of sampling
- the preservative used
- the name of the sampler
- the identification of the sample or site
- the test to be performed on the sample

The following table provides the EPA requirements, found in 40 CFR, Part 136, for critical wastewater parameters, for preservation, container, and holding time requirements.

Type of Sample and Holding Time

Parameter	Type of Sample	Holding Time	Sample Container
pH	Grab	Analyze Immediately	Plastic Bottle
Temperature	Grab	Analyze Immediately	Plastic Bottle
Dissolved Oxygen	Grab	Analyze Immediately	BOD Bottle
BOD	Composite Flow Proportional	48 Hours	Composite Sampler Plastic Bottles
Total Coliform Fecal Coliform E. Coli	Grab	Total 24-30 hours Fecal/E. Coli 6 Hour	Sterile Sample Plastic Bottle w/sodium thiosulfate
Chlorine Residual	Grab	Analyze Immediately	Opaque BOD Glass Bottle
Total Suspended Solids	Composite Flow Proportional	7 days	Composite Sampler Plastic Bottles
Specific Conductance	Grab	28 Days	Glass
Metals	Grab/Composite	6 Months	Amber Glass
TKN	Grab	28 Days	Plastic Bottle
Settleable Solids	Grab	48 Hours	Plastic Bottle

Preservation Conditions

Parameter	Container	Volume	Preservation	Holding Time	Representative Sampling Time
BOD	P	1 L	4°C	48 Hours	8 AM – 8 AM
TSS	P	1 L	4°C	7 Days	8 AM – 8 AM
TKN	P	.5 L	H ₂ SO ₄ PH < 2.0 4°C	28 Days	8 AM – 8 AM
Oils & Grease	GA	1 L	HCl or H ₂ SO ₄ PH < 2.0	28 Days	Between 8 AM and 12 PM
Metals	P	.2 L	HNO ₃ pH < 2.0	6 Months	8 AM – 8 AM
Phenols	G	.5 L	H ₂ SO ₄ pH < 2.0 40°C	28 Days	8 AM – 8 AM
Cyanides (T)	P	1 L	NaOH pH > 12.0 4°C	14 Days	2 PM
VOC	V	40 ml	4°C HCl pH < 2.0	14 Days	2 PM

G = Glass bottle with Teflon lined lid

GA = Amber bottle with Teflon lined lid

P = Plastic Bottle

V = Approved glass vials with Teflon and pure rubber seals

Note: All samples are refrigerated at 4°C after preservation.

9.0 SAMPLE CUSTODY

Chain-of-Custody encompasses three major elements:

- field sampling
- laboratory analysis
- final data file

A Chain-of-Custody (COC) form documents field activities and laboratory sample handling activities from time of receipt through the analytical process.

Samples may be physical evidence and should be handled according to certain procedural safeguards. All areas of the laboratory in which samples are received, stored, processed, or analyzed shall be kept in a condition that minimizes the risk of samples becoming lost or accidentally destroyed, contaminated, degraded, mis-identified, improperly handled or otherwise compromised.

9.1 Chain-of-Custody

EPA defines evidence of custody in the following manner:

- It is in your actual possession
- It is in your view, after being in your physical possession
- It was in your possession and then you locked or sealed it up to prevent tampering
- It is in a secure area.

Sample custody and sample control procedures ensure that:

- All samples are uniquely identified
- Samples are analyzed as requested and are traceable to their records
- Important sample characteristics are preserved
- Samples are protected from loss or damage
- Any alteration of samples (e.g., filtration, preservation) is documented
- A record of sample integrity is established for legal purposes

A Chain-of-Custody Form should be completed by field personnel for all samples received by the laboratory. The form should accompany the samples received at the laboratory. The completed Chain-of-Custody Form should include the following information (*refer to Attachment 13 for an example COC form*):

- Facility name
- Field sample number/identification
- Number and type of containers
- Date and time sampled
- Sample matrix
- Preservative
- Analysis requested
- Sampler signature
- Signature of person relinquishing samples

- Date and time relinquished
- Sampler remarks

The record must be filled out completely and legibly. Errors must be corrected by drawing a single line through and initialing and dating the error. The correct information is then recorded with indelible ink.

9.2 Receipt & Inspection

When samples are received by the laboratory the Chain-of-Custody must be signed by the receiving person. The receiving person, or designated employee, should verify the integrity of samples as they are unpacked. It should be noted whether the samples are received intact or broken, whether the samples are appropriately preserved and properly identified, the temperature of the container, and any other notable observations. This information should be documented on a sample condition form or a sample receipt logbook.

If the integrity requirements are met or after any discrepancies are resolved, the sample is assigned a unique laboratory identification or number and transferred to the appropriate storage location for storage until preparation and analysis. All samples must be stored at $4^{\circ}\text{C} \pm 2^{\circ}\text{C}$, or as specified in the specific method or SOP.

Once samples are in the laboratory, an internal custody record is generated to track the transport and status of each sample from storage to the laboratory and back to storage.

9.3 Subsampling for Sample Preparation or Analysis

In almost all cases, the laboratory receives more sample than is typically used for a specific analytical method. Therefore, a smaller aliquot, or subsample, must be obtained from the container for sample preparation or analysis. Obtaining a representative subsample, i.e. one that has the same characteristics and chemical composition as the original sample, can be difficult without employing complex techniques. In general, the following technique shall be used.

Aqueous Samples

Aqueous samples must be mixed by inverting the sample several times prior to pouring off an aliquot. This inversion must be performed for each subsequent test requiring an aliquot.

10.0 QUALITY CONTROL

A quality control program is a systematic process that controls the validity of analytical results by measuring the accuracy and precision of each method and matrix, by developing expected control limits, by using these limits to detect errors or out-of-control events, and by requiring corrective action techniques to prevent or minimize the recurrence of these events.

10.1 Method Detection Limits (where required)

Method detection limit (MDL) studies must be performed annually at a minimum for each method in use. MDL studies are also performed after any significant procedural or instrument configuration change.

Method detection limits should be determined using replicate spiked reagent grade or DI water samples. A minimum of seven replicates of a sample spiked with the analyte of interest is processed through the entire analytical method. The concentration of the detection limit sample should be between one and five times the anticipated detection limit.

The laboratory must calculate the detection limit as the student's t ($n-1$, $1-\alpha = 0.99$) times the standard deviation ($n-1$) of the replicate spiked sample measurements. *Refer to 40 CFR Part 136, Appendix B for further discussion.* The following are the specific steps taken to calculate an MDL:

- 10.2.1 A minimum of seven replicate analyses of reagent grade or DI water spiked with the analyte(s) of interest are analyzed by the appropriate analytical method on each instrument. All analytes that may be analyzed by a specific method should be included in the MDL study. All seven replicates need not be analyzed in the same batch. Sets of two or three MDL points may be analyzed as part of several analytical batches that are run on different days. Alternatively, one MDL point can be analyzed with every analytical batch and results compiled as needed (rolling MDL).
- 10.2.2 The concentration of analyte(s) spiked into the reagent grade or DI water should be equal to or in the same concentration range as the estimated MDL. A spike concentration between 1 and 5 times the estimated MDL is optimal.
- 10.2.3 Each spiked replicate is processed through all steps of the analytical method including any preparatory procedures and the results are calculated according to the procedures outlined in the given analytical method.
- 10.2.4 If a calibration curve is required to calculate the measured level of an analyte, the standards used to determine the curve should cover the range normally used for sample analysis. The curve should include a minimum of 3 standards and a blank unless the given analytical method or regulatory program requires a method-specific calibration protocol. The lowest calibration standard should be at a concentration 3-5 times the estimated MDL.
- 10.2.5 All QC samples required by each applicable method must be analyzed in conjunction with the MDL study. These QC samples may include, but are not necessarily limited to LCSs, method blanks, and calibration verifications/checks. If these criteria are not met then the MDL data may be suspect; the cause of the

problem should be investigated and the MDL study repeated.

10.2.6 The mean concentration (X), standard deviation (s) and MDL of the replicate analyses are calculated as follows for each analyte in the method:

$$X = S (x_i) / n$$

$$s = [S (x_i - X)^2 / (n-1)]^{1/2}$$

$$MDL = t_{(n-1), 1-\alpha = 0.99} * s$$

where, x_i = individual replicate measurement

n = number of replicates

t = student's t value

S = sum over n measurements

Attachment 14 provides an example MDL and contains the values for the student's t at 99% confidence.

10.2.7 A calculated MDL will be considered valid if the true concentration of the replicate spike lies within the range of 1-5 times the calculated MDL.

For example:

The calculated MDL for an analyte is 6 ug/L (standard deviation of the replicate measurement was 1.91 ug/L for 7 replicates) and the true concentration in the spiked replicates was 15 ug/L. The replicate spike is 2.5 times the calculated MDL; therefore, the MDL is acceptable.

The calculated MDL for an analyte is 6 ug/L (standard deviation of the replicate measurement was 1.91 ug/L for 7 replicates) and the true concentration in the spiked replicates was 50 ug/L. The replicate spike is 8.3 times the calculated MDL; therefore, the MDL is not acceptable. In this case the MDL study should be repeated using spiked replicates at a lower concentration, such as 25 ug/L.

10.2 Method Validation

The laboratory demonstrates its capability of performing an analytical method through method validation. Method validity is established by meeting specified criteria for precision and accuracy.

10.3 Accuracy and Precision Measurements

The results of quality control samples created in the laboratory represent estimates of accuracy and precision for the preparation and analysis steps of sample handling. This section describes the quality control information provided by each of these analytical measurements. Information on the procedures to follow in preparation of the samples or spiking solutions is described for each method and matrix in the respective method Standard Operating Procedure.

10.3.1 Method Blank

A method blank is a volume of analyte-free matrix (e.g. deionized and/or distilled laboratory water for water analyses) carried through the entire analytical procedure. The volume or weight of the blank must be approximately equal to the sample volume or weight processed. A method blank is performed with each batch of samples or one with every 20 field samples whichever is more frequent. Analysis of the blank verifies that method interferences caused by contaminants in solvents, reagents, glassware, and other sample processing hardware are known and minimized. Optimally, a method blank should be less than the PQL for all parameters unless otherwise specified in the method or SOP.

10.3.2 Accuracy Measurements

Laboratory Control Samples (LCSs) or **Laboratory Fortified Blank (LFB)** consist of aliquots of analyte-free matrices (water, sand, etc.) spiked with analytes of interest. Laboratory pure water is used to prepare most LCSs for methods for analysis of aqueous samples. LCSs provide an estimate of accuracy based on recovery of the compounds from a clean, control matrix. They provide evidence that the laboratory is performing the method within accepted guidelines generally in the absence of matrix interferences. They are prepared at a rate of one per batch of twenty or fewer samples.

Matrix Spikes/Matrix Spike Duplicates are similar to Laboratory Control Samples except the analytes used for spiking are added to a second and third separate aliquot from the field samples in a batch of analyses. They incorporate sample matrix effects and field conditions. Matrix spikes are routinely prepared at a frequency of one MS per twenty samples for inorganic analyses when adequate sample volume is provided.

Accuracy is expressed as Percent Recovery (%R). For LCSs, percent recovery (%R) is calculated using the following equation:

$$\%R = (SR / SA) * 100$$

where: **SR** is the concentration determined
 SA is the concentration spiked

For matrix spike samples, the percent recovery is calculated using the following equation:

$$\%R = (SSR - SR) / SA \times 100$$

where: **SSR** is the spiked sample determined result
 SR is the original sample determined result
 SA is the amount of spike added (expected)

10.3.3 Precision Measurements

A **Laboratory Duplicate** is a sample that has been homogenized and split into two equal portions before the method specified sample preparation process. It

measures sample precision associated with the preparation through analysis and is prepared and analyzed at a rate of one per batch or one per twenty samples (if a batch is less than twenty samples) in the inorganic laboratories.

The comparison of the values determined for a sample and its duplicate (S/DUP or MS/MSD) is expressed as relative percent difference (RPD). RPD is calculated using the following equation:

$$RPD = \frac{S-D}{[(S+D)/2]} \times 100$$

where: S is the determined result of the original sample
D is the determined result of the duplicate sample

The vertical bars in the above equation indicate the absolute value of the difference, hence RPD is always expressed as a positive value.

10.3.4 Statistical Control Limits

Statistically derived laboratory limits serve as a tool for evaluating method performance, for evaluating individual analyst performance and for monitoring the effects of changes to the analytical methods. Statistically derived QC limits should be calculated as 3 standard deviations from the mean recovery of a minimum of twenty data points. This may be done on an annual basis for Laboratory Control Samples and/or matrix spike/matrix spike duplicates if sufficient data is available. A minimum of twenty data points are required for a given analytical procedure and sample matrix prior to generating statistical control limits. Until twenty data points are available, recommended EPA recovery limits must be used if available. Data points shall be chosen at random. All data points used in the determination must be taken from data where all routine applicable QC criteria have been met for the analysis.

The percent recovery is calculated for each spiked analyte. The average percent recovery (X) and the standard deviation (s) are calculated for the group of samples.

Both upper and lower warning limits and upper and lower control limits are established to interpret performance. Warning limits express a narrower confidence interval and are used to warn the technician of possible system inconsistencies or failures, before an out-of-control event occurs. Control limits express the outer limits of accepted method variability. Control limits and warning limits are reviewed periodically against performance. Based on statistical considerations, an evaluation is made to determine whether the control limits need to be revised.

Warning Limits

When not mandated by the method, warning limits should be the mean ± 2 standard deviations or a 95% confidence interval, where:

The mean percent recovery and standard deviation are calculated as follows:

$$\text{Mean}(P) = \frac{1}{n} \sum_{i=1}^n X_i$$

Standard Deviation(s) =

$$S^2 = \frac{\sum_{i=1}^n X_i^2 - \left(\frac{1}{n}\right) \left(\sum_{i=1}^n X_i\right)^2}{n-1}$$

where: X = individual values
N = total number of values

Recovery warning limits are to be calculated using the following formulas:

$$\begin{aligned}\text{UWL} &= P + 2s \\ \text{LWL} &= P - 2s\end{aligned}$$

where: UWL = Upper Warning Limit
LWL = Lower Warning Limit

Control Limits

Unless otherwise specified by the analytical method in use the 99% confidence interval is used as the control limits, which is defined as the mean ± 3 standard deviations. Where the method specific ranges have been determined, control limits should be similar to the method limits. Control limits are established as follows using the mean and standard deviation as above:

$$\begin{aligned}\text{UCL} &= P + 3s \\ \text{LCL} &= P - 3s\end{aligned}$$

where: UCL = Upper Control Limit
LCL = Lower Control Limit
P = Mean Percent Recovery
s = Standard Deviation

The control limits and warning limits used to evaluate a sample should be those in place at the time that the sample was analyzed. Once limits are updated, the limits should apply to all subsequent analyses.

10.3.5 Control Charts

Control charts are quality control tools that graphically display the QC parameters over time. The lab may generate control charts as a means to identify method or analyst performance issues.

10.3.5.1 Accuracy

Accuracy charts can be used for Laboratory Control Sample recovery.

The percent recovery is plotted onto the graph where:

the x-axis is the sample ID; and
the y-axis is the range of percent recoveries.

10.3.5.2 Precision

Precision charts can be used for LCS/LCSD and MS/MSD comparison.
The relative percent difference is plotted on the graph where:

the median, zero, represents 0% difference
the x-axis is the number of data points per chart; and
the y-axis is the range of relative percent differences.

Control chart limits may be evaluated using the following guidelines.

Suspicious/Out-of-Control Events

Plotting and connecting successive data points on control charts enables the laboratory to detect many types of suspicious and out-of-control situations. These events can be caught by monitoring the following: outliers (suspicious and out-of-control), runs (suspicious), trends (suspicious), and periodicity (suspicious).

Outliers

There are two types of outliers: any particular point that falls outside the control limits or any point that falls outside the warning limits. A point that falls outside the control limits is classified as an out-of-control event; a point that falls outside the warning limits is classified as a suspicious event.

Runs

A run is defined as a series of points that line up on one side of the central line (the mean). Any run that has a length of seven points is indicative of a potential abnormality in the process, a suspicious event. A run can suggest several potential problems such as a leak in the system, elevated contamination, or incorrect dilutions of standards.

Trends

A trend is defined as a series of points that are marked by an unbroken rise or fall. Any trend with a length of five points is classified as a suspicious event. A trend may indicate a change in instrument sensitivity due to a dirty source or injection port or standard degradation, to name a few.

Periodicity

Periodicity is a term used to describe a recurring pattern of change over equal intervals. This occurrence may be of any length or amplitude; thus, careful observation of the control chart is necessary.

Refer to Attachment 15 for an example control chart.

11.0 ANALYTICAL METHODS & SPECIFIC QC

Analytical procedures are detailed descriptions of any and all processing, preparation and analysis of samples in the laboratory. In some instances, data format, presentation and delivery are also described. All analytical procedures shall be conducted in strict adherence to the QA Manual and written Standard Operating Procedures that have been reviewed and approved by the appropriate personnel.

The method SOPs should contain specific requirements for all QC samples. Table 11-1 lists minimum DEP requirements for QC parameters. Other analytical issues are described below:

11.1 Settleable Solids (SS)

- Do not estimate floating material as settleable matter.
- Record the results in mL/L/hr.

11.2 Total Residual Chlorine (TRC)

- An amber bottle must be used because chlorine dissipates rapidly in sunlight.
- The bottle should be completely filled because chlorine dissipates with the atmosphere.

11.3 Biochemical Oxygen Demand (BOD)

- Sample and dilution water must be 20 °C.
- Initial DO must be < 9 mg/L.
- Blank depletion must be <0.2 mg/L.
- Sample residual DO must be > 1 mg/L.
- Sample DO depletion must be >2 mg/L.

11.4 Total Suspended Solids (TSS)

- Excessive solids on the filter may leave a residue that can form a water trapping crust. To guard against this problem, the selected sample volume should produce no more than 200 mg of residue.

11.5 pH

- The pH meter should be capable of reading to at least 2 digits beyond the decimal place, i.e. 7.43, not 7.4.
- The pH probe should have temperature compensation.
- The pH meter should be warmed before use for at least 30 minutes.
- The pH meter should be standardized with at least two buffers that will bracket the readings of the samples.
- A third buffer should be read as a check sample.
- The probe should be rinsed with DI water between samples and buffers.

11.6 E. coli / Fecal coliform

- All equipment must be sterilized with autoclave, UV light, alcohol or flame.

11.7 Temperature

- Temperature should be measured on-site.
- Temperature conversions:

$$^{\circ}\text{C} = \frac{(^{\circ}\text{F} - 32) \times 5}{9}$$

$$^{\circ}\text{F} = \frac{(^{\circ}\text{C} \times 9)}{5} + 32$$

11.8 Phosphorus

- Samples must be digested prior to analysis

Table 11-1

Parameter	Calibration/ Standardization	QC Standards	Duplicates/ Replicates	Spikes	Blanks
Ammonia	As per method	1/10 Tests	1/10 Tests	1/Yr	1/each
BOD	Meter before each use	1/10 Test IGGA/Each if seeded	1/10 Tests	1/Yr	1/each
Chlorine Residual Meter	Check standard curve daily standard for each use	1/month	1/10 Test	1/Yr	1/each
Titrimetric	FAS stand 1/month	1/month	1/10 Test	1/Yr	1/each
COD	As per method	1/10 Test	1/10 Test	1/Yr	1/each
Cyanide	As per method	1/each	1/each	1/each	1/each
E. Coli	Additional QC required for E. Coli includes equipment sterility checks (indicator tape, "Kilit" ampules) each tests and pH check of dilution water ($7 > 1 \pm .2$) each test	2/Yr /POS control/each test	1/each	N/A	1/each
Metals	As per method	1/each	1/each	1/each	1/each
Nitrate Nitrogen	As per method	1/10 Tests	1/10 Tests	1/Yr	1/each
Oil & Grease	As per method	1/each	1/each	1/Yr	1/each
PH	Minimum 2 point calibration each use	(3 rd buffer) 1/each	1/10 Tests	N/A	N/A
Phosphorus	5 Standards/each	1/10 Tests	1/10 Tests	1/Yr	1/each
Settleable Solids	N/A	N/A	1/10 Tests	N/A	N/A
Total Suspended Solids	Constant weights before and after filtering sample	1/10 Tests	1/each	N/A	1/each

12.0 DOCUMENTATION & RECORDS MANAGEMENT

Records are the means by which an organization documents its operations and activities. They are an integral part of the Quality Assurance program since they provide documented evidence for program functionality and necessary information for proficiency testing and quality assurance audits. All information related to the quality assurance practices outlined in this manual shall be contained in records. This shall include, but not be limited to:

- standard operating procedures
- results of instrument calibrations
- analysis of quality control samples
- analysis of samples
- sample custody and disposal
- preparation of standards
- COC documentation
- analytical records
- corrective action reports
- audits and inspections

12.1 General Recordkeeping

- 12.1.1 All documentation must be accurate, legible, complete and recorded in a timely manner using indelible ink. No measurements are to be filled in ahead of time even if the measurement is always the same. During the actual analysis it may be determined that a different quantity is needed.
- 12.1.2 All data and/or results that are recorded and/or entered must be a true and accurate representation of the measured values and must be validly quantitated.
- 12.1.3 If an error is made, a single line is used to cross out the incorrect entry. The original entry must remain readable. The correction must be initialed and dated and given an explanation for the change. The use of white out is prohibited on all raw data, including instrumental hardcopy.
- 12.1.4 When blank space is left after all information has been recorded on a logbook page or in other documentation, that blank space must be "Z'd" out. Use a single line through the space; initial and date the cross out.
- 12.1.5 All blocks must be filled in on pre-printed forms. Header information must be complete. All columns and units of measure must be identified.

12.2 Standard Operating Procedures

Standard Operating Procedures (SOPs) are written for specific procedures or operations. Complex tasks of inspection, testing, calibration, monitoring, maintenance, data handling, and quality control as well as methods utilized in the laboratory are specified and documented by SOP. More detailed information regarding SOPs can be found in Section 4.0. All personnel are required to follow SOPs when a specific operation or method is being utilized.

12.3 Sample Tracking

Samples are tracked from the time they are received, through storage, preparation, analysis, and final disposition. Proper sample identification must be established during sample collection. This information must be clearly and permanently written on a label and attached to the sample. In addition, a Chain-of-Custody must be initiated with the appropriate information recorded. Samples should also be properly preserved and stored.

12.4 Standards

Standards preparation is documented in the standards logbooks maintained by the laboratory. All information needed to maintain proper traceability of standards is recorded in the appropriate standards logbook by the individual preparing the standard. More complete information regarding standards is provided in Section 6.0.

12.5 Maintenance Logbooks

A maintenance logbook should be kept for all instruments. Each instrument should have a unique page in the maintenance logbook. In the logbook, an analyst records initial instrument setup, routine preventive maintenance, outside contractor services, instrumental malfunctions and repair performed, dates taken in and out of service, and resolutions. Instrument logs not only describe the instrument's history, but can be helpful when troubleshooting. Additionally, runlogs may describe problems noted, maintenance performed and return to control. *Refer to Attachment 16 for an example maintenance logbook.*

12.6 Bench Logbooks (preparation & analysis)

All data pertinent for sample preparation and analysis shall be recorded by the laboratory staff in bound notebooks. *Refer to Attachment 17 for example benchsheets.* It shall contain the following information:

- Sample identification numbers
- Date of preparation and analysis
- Method reference
- Analyst's initials
- Preparation weights and/or volumes (initial and final)
- Reagent/solvents used including manufacturer and lot number
- Relevant blank
- Spike data including the serial reference number
- Notable observations
- Entire sequence of samples, including the calibration curve
- Identification of the instrument
- Acceptability of the results in the context of the QC system.
- Amount analyzed and any dilution of the original sample and/or extract
- Any data relevant to the calculations

13.0 DATA REDUCTION, VALIDATION AND REPORTING

All analytical data generated within the laboratory must undergo a well-defined, well-documented multi-tier review process.

13.1 Data Reduction/Documentation

All raw data are recorded on a standardized recording form. *Refer to Attachment 17 for example benchsheets.* The analyst conducting the analysis records, at a minimum:

- method used
- date of analysis
- raw data readings
- calculations
- final results
- analyst's initials or signature

Any deviations from standard data reduction procedures must also be recorded.

All data and/or results that are recorded and/or entered must be a true and accurate representation of the measured values and must be validly quantitated.

All documentation must be accurate, legible, complete and recorded in a timely manner using indelible ink. No measurements are to be filled in ahead of time even if the measurement is always the same. During the actual analysis it may be determined that a different quantity is needed.

If an error is made, a single line is used to cross out the incorrect entry. The original entry must remain legible. The correction must be initialed and dated and given an explanation for the change. The use of white out is prohibited on all raw data, including instrumental hardcopy.

When blank space is left after all information has been recorded on a logbook page or in other documentation, that blank space must be "Z'd" out. Use a single line through the space; initial and date the cross out.

All blocks must be filled in on pre-printed forms. Header information must be complete. All columns and units of measure must be identified.

For data, which are reduced by manual calculations, an example calculation must be documented in a laboratory notebook or on an analyst's worksheet.

All reduced data must be evaluated by the analyst using the QA acceptance criteria found within each analytical method SOP.

13.2 Significant Figures

To avoid reporting results that are inaccurate or deceiving, "significant figures" are used. Significant figures give an indication of the reliability of the analytical method used. Reported values should only contain those values that are significant. A value is made up

of significant figures when it contains all digits known to be true and one last digit in doubt. For example, in the number 21.2, the 21 is a firm value, but the 2 may be a one or a three. This value is in doubt. This number contains 3 significant figures. Refer to the following table for required significant figures.

Parameter	Significant Digits
BOD – No digit after decimal point	28 mg/L
Chlorine Residual – Two digits after decimal point	0.51 mg/L
Coliform – No digits after decimal point	50/100 ml
TKN, NH ₃ , NO ₃ – One digit after decimal point	17.6 mg/L
DO – Two digits after decimal point	7.35 mg/L
Settleable Solids – One digit after decimal point	5.1 ml/L
Metals – One digit after decimal point	436.3 ppb
pH – Two digits after decimal point	7.00 pH units
Suspended Solids – No digit after decimal point	22 mg/L
Temperature – One digit after decimal point	17.2°C

13.3 Rounding

The following rounding rules shall be used when determining the correct number of significant figures. The number of significant figures varies with the test performed (see table above).

All digits are used in calculation, then are rounded, using the following guidelines. Numbers that are not significant must be dropped by rounding off. If the digit 5, 6, 7, 8, 9 is dropped round up one unit. If the digit 0, 1, 2, 3, 4 is dropped, do not change the preceding digit.

For example:

3.57 is rounded to 3.6
2.41 is rounded to 2.4
4.44 is rounded to 4.4
7.35 is rounded to 7.4
7.65 is rounded to 7.6

13.4 Data Validation

The analyst who completes the analysis assembles:

- all relevant raw data and results
- strip chart recordings
- spreadsheet calculations
- instrument settings and/or other essential information to data interpretation

The calculations and final results recorded on the recording forms or laboratory notebook are reviewed and initialed by a second qualified reviewer. The reviewer checks the data recording forms and completed worksheet for accuracy, consistency, and

fulfillment of quality control criteria. All manual calculations are checked and 10% of all spreadsheet calculations are checked. The remainder of spreadsheet calculations are spot checked for potential anomalies. The reviewer approves the worksheet by initialing it.

14.0 PREVENTIVE MAINTENANCE

To minimize downtime and interruption of analytical work, preventive maintenance is routinely performed on each analytical instrument. Designated laboratory personnel are trained in routine maintenance procedures for all major instrumentation. When repairs are necessary, they are performed by either trained staff or instrument manufacturer service personnel.

SOPs are written for each instrument that cover basic operation and maintenance procedures. Detailed logbooks documenting preventive maintenance, non-routine maintenance and repairs are also maintained for each instrument. The following are brief summaries of maintenance for each major instrument.

14.1 Preventive Maintenance - General Laboratory Areas

- Clean and calibrate balances biannually (minimum)
- Check balance calibration each day of use
- Clean balance pan prior to each use
- Calibrate automatic pipettes with each use
- Calibrate thermometers yearly against an NIST traceable thermometer
- Record refrigerator, freezer, and oven temperatures each weekday
- Clean, check, calibrate to manufacturers' specifications all pH, DO, conductivity, spectrophotometers, and turbidity meters annually (recommended) using an outside service
- General housekeeping: keep counter tops, hoods, and floors clean
- Check airflow in hoods once a week

14.2 DO Probe Preventive Maintenance

- Visually inspect the probe membrane for tears, oily residues, or fingerprints
- Inspect for air bubbles under the membrane. If any of the above are present, replace the membrane cap
- Replace electrolyte solution when membrane cap is replaced

15.0 PERFORMANCE AND SYSTEM AUDITS

Proficiency Test samples (PTs) may be analyzed periodically to verify method accuracy. These PT samples may be external (e.g. DMR-QA) or internal (prepared or purchased). DMR-QA samples must be analyzed annually.

15.1 Proficiency Test (PT) Samples – DMR-QA - Annual

EPA requires some laboratories to perform annual Quality Assurance tests on samples containing unknown quantities of specific analytes. The laboratory must obtain the samples from an approved PT provider. The samples are analyzed for prescribed analytes. The quantities of analytes found in the samples are reported to the contractor who issues a report to the analyzing laboratory and to the Maine DEP stating whether the analyses performed gave results within allowable limits. If the result from any analysis falls outside the acceptable limits, the analyzing laboratory should determine the reason for failing the test and implement corrective actions. This may include ordering another sample for reanalysis to determine if the problem has been found and solved.

15.2 Periodic Internal Audits

In the event that the overseeing regulatory agency requires an internal audit, the following would apply: internal auditing is conducted by a designated person. These audits should focus on performance relative to an SOP. Internal audits take two forms - performance audits and systems audits.

15.2.1 Performance Audits involve analysis of blind spikes obtained from an outside service. These samples may be performed if results for a particular method are in question. Analyzing a known sample is a good way to determine whether a problem may or may not exist.

15.2.2 Systems Audits consist of a thorough review of procedures and documentation to confirm that work is being performed in accordance with this Manual and SOPs. They should be performed by an individual with knowledge of laboratory procedures. Audit checklists may be used to ensure that all points are addressed and documented.

Audit checklists may cover at least the following areas:

- Personnel qualifications and training records
- Adequacy of laboratory facilities, including work space, lighting, ventilation, and supplies
- Maintenance and calibration recordkeeping for analytical equipment
- General operations, including glassware cleaning, inventory and checking of reagents and standards, and storage procedures
- Recordkeeping, including sample log-in and tracking, traceability of standards, control charts, and raw data recording and tracking.

A summary of the audit findings should be written by the auditor. Any corrective actions to be taken should also be explained. The report should be filed for future reference.

16.0 CORRECTIVE ACTION

For most laboratory situations, problem identification, corrective action, and resumption of operation and/or return to control occurs at the bench, with documentation written directly in the appropriate logbooks or benchsheets. These occurrences include events where laboratory quality control criteria have been exceeded but which can be corrected without compromising the analytical results or delaying the preparation or analytical process.

For other situations, problem identification, corrective action, and resolution are tracked via Corrective Action Reports (CARs). CARs (*Refer to Attachment 18 for an example CAR*) should be initiated:

- **When Quality Control criteria are not met** - These QC criteria include, but are not limited to, blanks, LCSs, spikes, ICVs/CCVs. *Note: it may not be necessary to initiate a CAR in each case, especially if data is rejected, but the corrective action should be documented on the raw data, logbook or other analyst records.
- **When laboratory SOPs are not followed** - This includes all aspects of laboratory operations from receipt to reporting.
- **When you are concerned that a major problem or potential problem exists in the laboratory.**

The underlying purpose of the corrective action process is to identify instances that may adversely affect the data. Corrective actions also help:

- **To help standardize the laboratory's procedure for handling events that require corrective action** - Every situation should be evaluated individually, but there are some basic guidelines that should be followed.
- **To record actions taken when SOPs are not followed so that the data produced is supported with a documented sequence of events.**
- **To document occurrences in the lab that may affect the integrity of laboratory records**
- **To provide a learning tool for individuals involved in the problem investigation and corrective action plan**
- **To provide a means for tracking recurring problems that may need further investigation into the root cause of the problem.**

16.1 Problem Identification

The analyst generating the data is responsible for reviewing all results against the established limits. Any deviations are immediately evaluated as potential out-of-control events. Specific examples of some out-of-control events may be: Laboratory Control Sample (LCS) failures, blank contamination, poor precision, prep errors, missed holding times, calibration failures, and matrix spike failures. If data are outside accepted limits, the analyst should review and evaluate the data and all associated Quality Control elements together before making a decision as to the acceptability of the data. Each

individual method SOP contains corrective action tables to help guide analysts in making these decisions. Once all QC items have been considered, the analyst should immediately take the appropriate actions.

16.2 Corrective Action

The appropriate action will differ with each situation. In some cases data may be reported, but may be reanalyzed in other cases. Making new reagents and standards may be necessary if the standardization is suspect. The corrective actions listed in every method SOP may rely on analyst experience to make sound scientific judgements. These decisions may be based upon whether there is remaining analyte holding time.

The return of control of the measurement, confirmed by data within acceptable limits as set by the manufacturer, SOP or policy, prove completion of corrective action.

The following are some examples of possible corrective actions that may be taken for several out-of-control events. In all cases the corrective action taken shall be documented in a logbook or in a CAR, whichever is appropriate.

16.2.1 Method Blanks (when required by the SOP)

Corrective action is taken whenever the analyte is detected in the method blank above the reporting limit or PQL (Practical Quantitation Limit):

- Check all calculations
- If samples are non-detect, the high blank has not biased the sample. Report data with no qualifier
- If sample concentrations are significantly greater than the blank level (i.e. 10X), the sample is not significantly impacted by the blank. Report sample results with a qualifier indicating the blank level
- If sample concentrations are between the PQL or reporting limit and 10X the blank level, they should be reanalyzed and/or reextracted/redigested
- Investigate the source of the problem

16.2.2 Laboratory Control Samples (when required by the SOP)

The % recovery of Laboratory Control Samples (LCS) is calculated. Corrective action is taken whenever the % recovery is outside the established acceptance criteria. The following corrective actions are taken when required:

- Check calculations to assure there are no errors
- Check internal standard and spiking standard solutions for degradation, contamination, etc., and check instrument performance
- If LCS fails high and samples are non-detect, report associated data with a narrative explanation

- Reanalyze other samples associated with a failed LCS, if available

16.2.3 Matrix Spike and Matrix Spike Duplicates (when required by the SOP)

The % recovery of Matrix Spike and Matrix Spike Duplicates are calculated. The following corrective actions are taken when required:

- If all QC associated with a sample is within acceptance limits (method blank and LCS spike recoveries), the problem may be attributed to a matrix effect

16.2.4 Calibration

Individual methods specify calibration frequency and criteria. If the calibration curve is suspect, the following steps should be taken:

- Check instrument for contamination
- Check instrument for incorrect operating conditions
- If no source of the problem is identified, then a complete initial calibration must be performed

16.3 Documenting Corrective Action

All corrective actions shall be documented on a Corrective Action Report as soon as possible after problem identification. The following information must be documented on the CAR:

- When and where the out-of-control event occurred
- The person who discovered the out-of-control event
- What analysis was being performed
- What samples are affected by the out-of-control event
- A brief description of the out-of-control event
- Steps taken to investigate the out-of-control event
- The probable cause of the out-of-control event
- Any corrective actions taken, both immediate and long term to prevent reoccurrence

16.4 Review of Corrective Action

All corrective action reports must be reviewed by the appropriate management personnel. Historical corrective action reports may be reviewed to identify long-term trends or recurring problems. The root cause of the problem shall be identified as: lack of organization, lack of resources, lack of training, lack of time, lack of discipline or lack of top management support. All documentation associated with the CAR, i.e. raw data or reissued reports shall be filed.

ATTACHMENTS

Attachment 1
Terms, Definitions & Acronyms

<u>Accuracy:</u>	The closeness of agreement between an observed value and an accepted reference value. When applied to a set of observed values, accuracy will be a combination of a random component and of a common systematic error (or bias) component.
<u>Aliquot:</u>	A measured portion of a sample taken for analysis.
<u>Analyte:</u>	The specific component or constituent that the analytical measurement seeks to determine.
<u>Batch:</u>	A group of samples which are treated similarly with respect to the sampling or the testing procedures being employed and which are processed as a unit. For QC purposes, if the number of samples in a group [first] is greater than 20, then each group [successive] of 20 samples or less will all be handled as a separate batch.
<u>Blank:</u>	See Equipment Rinsate, Method Blank, Trip Blank, Field Blank, Calibration Blank.
<u>Blind Sample:</u>	A sample submitted for analysis whose composition is known to the submitter but unknown to the analyst.
<u>Calibration:</u>	The process of establishing the relationship between instrumental response and known traceable quantities of analytes of interest.
<u>Calibration Blank:</u>	A quality control sample prepared in the same manner as calibration standards with the exception of the addition of the analytes of interest. A calibration blank is used to establish solvent/reagent and system contributions to the analytical result.
<u>Calibration Verification</u>	The process of analyzing a mid-level calibration standard to verify the validity of the calibration curve.
<u>Comparability:</u>	Comparability is a qualitative parameter expressing the confidence with which one data set can be compared to another. Comparable data are produced through the use of standardized procedures and techniques.
<u>Completeness:</u>	Measure of the amount of valid data obtained from a measurement system compared to the amount that was expected to be obtained under correct normal conditions
<u>Composite Sample:</u>	A collection of individual samples obtained at set intervals over a period of time.
<u>Continuing Calibration:</u>	The process of analyzing standards periodically to verify the maintenance of calibration of the analytical system.

<u>Control Chart:</u>	A graphical plot of test results with respect to time or sequence of measurement, together with limits within which they are expected to lie when the system is in a state of statistical control.
<u>Control Limit:</u>	A range within which specified measurement results must fall to signify statistical control. A process is considered in control if data falls within the prescribed limits. A process is considered "out-of-control" if data falls outside the established control limits. These data are considered suspect and require corrective action including, but not limited to, qualification of the data.
<u>Data Quality: Objective</u>	Qualitative and quantitative statements that define the appropriate type of data, and specify tolerable levels of potential decision errors that will be used as the basis for establishing the quality and quantity of data needed to support decisions.
<u>Data Validation:</u>	The internal process of review by which data are shown to be valid as evidenced by the soundness of the analytical system.
<u>Deionized Water:</u>	Water that has been deionized to produce reagent grade water. Refer to reagent grade water.
<u>Dilution:</u>	Lowering the concentration of a solution by adding more solvent (usually distilled water).
<u>Dry Weight:</u>	The weight of a sample based on percent solids. The weight after drying in an oven following lab protocol.
<u>Effluent:</u>	The output or discharge from a water treatment process.
<u>Equipment Blank:</u>	A field blank used to verify the effectiveness of equipment decontamination procedures. Laboratory deionized water is passed over sampling equipment after decontamination, collected, and analyzed by the lab.
<u>Field Blank:</u>	Samples of analyte-free media (generally water) taken from the laboratory to the field as: 1) distinct aliquots in the same containers used to collect samples with the appropriate preservative reagents added, or; 2) a single reserve to be aliquoted in the field into the appropriate containers with the appropriate preservatives for the parameters of interest. The intent of the field blank is to ascertain and document any contamination attributable to shipping, field handling procedures and potentially to ambient conditions.
<u>Field Duplicate:</u>	Independent samples that are collected as close as possible to the same point in space and time. They are two separate samples taken from the same source, stored in separate containers and analyzed independently. These duplicates are useful in documenting the precision of the sampling process.

<u>Field Sample:</u>	A portion of material received by the laboratory to be analyzed, that is contained in single or multiple containers and identified by a unique field ID number.
<u>Grab Sample:</u>	A single sample of wastewater.
<u>Holding Time:</u>	The elapsed time expressed in days (except for parameters requiring analysis in ≤ 48 hours) from the date of sample collection by the field personnel until the date of its processing/analysis. Holding time requirements are dictated by the EPA Federal Register 40CFR Part 136, Table II.
<u>Homogeneity:</u>	The degree to which a property or substance is evenly distributed throughout a material.
<u>Influent:</u>	Wastewater or other liquid flowing into a reservoir, basin, treatment process or treatment plant.
<u>Instrument Detection Limit:</u>	Smallest signal above background noise that an instrument can detect at a 99% confidence level that the analyte concentration is greater than zero. The IDL does not consider any effects that the sample matrix, handling or preparation may have.
<u>Initial Calibration:</u>	The process of analyzing standards, prepared at specified concentrations, to define the quantitative response, linearity and dynamic range of the instrument to the analytes of interest. Initial calibration is performed whenever the results of a continuing calibration do not conform to the requirements of the method in use or at a frequency specified in the method.
<u>Lab Control Sample:</u>	A control sample whose matrix is of known composition or analyte-free matrix spiked with a known concentration of analytes of interest. Laboratory control samples are handled using the same preparation, reagents, and analytical methods employed for field samples. Laboratory Control Samples are utilized as indicators of the accuracy of the analysis.
<u>Lab Duplicate:</u>	Aliquots of sample taken from the same container and analyzed independently. In cases where aliquots of samples are impossible to obtain, field duplicate samples should be taken for the matrix duplicate analysis. These are usually taken after mixing or compositing and are used to document intra- or interlaboratory precision.
<u>Lot:</u>	A quantity of bulk material of similar composition processed or manufactured at the same time.
<u>Matrix:</u>	The component or substrate (e.g. surface water, drinking water) which contains the analyte of interest.

<u>Matrix Duplicate:</u>	An intralaboratory split sample which is used to document the precision of a method in a given sample matrix.
<u>Matrix Spike:</u>	Aliquot of sample fortified (spiked) with known quantities of specified analytes and processed through the entire procedure in order to indicate the appropriateness of the method for the matrix by measuring recovery.
<u>Matrix Spike Duplicate:</u>	Intralaboratory split samples spiked with identical concentrations of target analyte (s). The spiking occurs prior to sample preparation and analysis. They are used to document the precision and bias of a method in a given sample matrix.
<u>Meniscus:</u>	The curved top of a column of liquid in a small tube. When the liquid wets the sides of the container (as with water), the curve forms a valley.
<u>Method Blank:</u>	An analyte-free matrix to which all reagents are added in the same volumes or proportions as used in sample processing. The method blank should be carried through the complete sample preparation and analytical procedure. The method blank is used to document analyte contribution resulting from the analytical process. Acceptable levels of contamination are defined in individual SOPs and/or by project specific data quality objectives.
<u>Method Detection Limit:</u>	The statistically derived minimum concentration of a substance that can be measured and reported with 99% confidence that the analyte concentration is greater than zero. Method detection limits are determined using replicate spike samples prepared by the lab and taken through all preparation and analysis steps of the method. The method detection limit is calculated using the appropriate Student's t parameter times the standard deviation of a series of spiked samples.
<u>NPDES permit:</u>	National Pollutant Discharge Elimination System permit, the legally enforceable document that sets forth the terms, conditions and limitations by which a wastewater treatment system must operate. The NPDES is authorized by both state and federal law and it allows stiff civil and criminal penalties for failure to comply. NPDES permits must be obtained for all point source discharges into US waterways. NPDES permits are administered in Maine by the DEP. The program is referred to as MEPDES.
<u>Performance Audit:</u>	A process to evaluate the compliance of actual laboratory practices with relevant project requirements, regulations, contract specifications or internally stated standard operating procedures and practices.
<u>Precision:</u>	The agreement among a set of replicate measurements without assumption of knowledge of the true value. Precision is estimated by means of duplicate/replicate analyses. These samples should contain concentrations of analyte above the MDL, and may involve the use of

matrix spikes. The most commonly used estimates of precision are the relative standard deviation (RSD), when two or more samples are available and the relative percent difference (RPD), when only two samples are available.

Preservative: A chemical or reagent added to a sample to prevent or slow decomposition or degradation of the analyte to be tested.

Proficiency Test: A process to evaluate the proficiency of an analyst or laboratory by evaluation of the results obtained on known test materials.

Protocol: A stated plan that clearly defines the objectives, methods and procedures for accomplishing a task.

PQL: Practical Quantitation Limit; a value three to five times the Method Detection Limit.

Quality Assurance Program: A system of policies and procedures whose purpose is to ensure, confirm and document that the product rendered fulfills the requirements of Facility Name. Quality Assurance includes quality planning, quality control, quality assessment (auditing), quality reporting and corrective action.

Quality Control: A system of checks and corrective measures, integrated with the activities that directly generate the product or service, that serves to monitor and adjust the process to maintain conformance to predetermined requirements.

Reagent-Grade Water: Water that has no detectable concentration of the element or compound to be analyzed at the detection limit of the method and water that is free of substances that interfere with the method. This determination is dependent on the analytical test (detection limit and interferences) to be used. See deionized water.

Replicate: A second measurement made on the same aliquot of sample, sample extract or sample digestate to assist in the evaluation of precision of analysis. This is not a lab duplicate. A lab duplicate is performed on the same sample, but not the same sample aliquot.

Reporting Limit: The level at which method, permit, regulatory and client specific objectives are met. The reporting limit may never be lower than the statistically determined MDL, but may be higher based on any of the above considerations. Reporting limits are corrected for sample amounts, the dry weight of solids, and instrument dilution factors, unless otherwise specified.

<u>Sensitivity:</u>	Capability of methodology or instrumentation to discriminate between samples having different concentrations or containing differing amounts of an analyte.
<u>Significant Figures</u>	The number of digits in a value that are justified by the accuracy and precision of the method being used. A value is made up of significant figures when it contains all digits known to be true and one last digit in doubt.
<u>Spike:</u>	Aliquot of sample or deionized water fortified (spiked) with known quantities of specified analytes and processed through the entire procedure in order to indicate the appropriateness of the method for the matrix by measuring recovery. See also matrix spike and Lab Control Sample.
<u>Standard:</u>	A substance or material the properties of which are known with sufficient accuracy to permit its use to evaluate the same property in a sample.
<u>Standard Operating Procedure:</u>	A written document that details the method for an operation, analysis, or action with thoroughly prescribed techniques and steps that outline expected limits of achievement and will produce consistent performance with repetitive use. This document must be officially approved as the method for performing certain routine or repetitive tasks.
<u>Superintendent:</u>	Senior responsible official. This may be a Chief Operator, Lab Supervisor, Town Manager, or Mill Manager.
<u>Systems Audit:</u>	An on-site inspection or assessment of a laboratory's quality system or one of its components.
<u>Titration:</u>	Process in which an accurate volume of a titrant (known concentration) is dispensed into a known volume of sample (unknown concentration)
<u>Traceability:</u>	The ability to trace the source and accuracy of a material (i.e., standard) to a recognized primary reference source such as the National Institute of Standards and Technology (NIST) or USEPA. Also, the ability to independently reconstruct and review all aspects of the measurement system through available documentation.
<u>Trip Blank:</u>	A sample of analyte-free media taken from the laboratory to the sampling site and returned to the laboratory unopened. A trip blank is used to document contamination attributable to shipping and field handling procedures. This type of blank is useful in documenting contamination of volatile organics samples.
<u>Validation:</u>	The internal process of review by which data are shown to be valid as evidenced by the soundness of the analytical system and successful meeting of the DQOs (not to be confused with data validation by an outside independent source).

Warning Limits:

The limits (typically 2 standard deviations either side of the mean) within which most analytical results are expected to lie with a 95% probability while the system remains in a state of statistical control.

ACRONYMS

AA	Atomic Absorption
ACS	American Chemical Society
CAR	Corrective Action Report
CCB	Continuing Calibration Blank
CCC	Calibration Check Compounds
CCV	Continuing Calibration Verification
CDP	Continued Demonstration of Proficiency
COC	Chain-of-Custody
DMR	Discharge Monitoring Report
GC	Gas Chromatograph
GCMS	Gas Chromatograph Mass Spectrometer
GFAA	Graphite Furnace Atomic Absorption
GLP	Good Laboratory Practices
HDPE	High Density Polyethylene
IC	Ion Chromatography
ICB	Initial Calibration Blank
ICP	Inductively Coupled Plasma (Spectrophotometer)
ICV	Initial Calibration Verification
IDL	Instrument Detection Limit
IDP	Initial Demonstration of Proficiency
LCS(D)	Laboratory Control Sample (Duplicate)
LRS	Linear Range Standard
MDL	Method Detection Limit
MS(D)	Matrix Spike (Duplicate)
NBS	National Bureau of Standards
NIST	National Institute of Standards Traceability
OSHA	Occupational Health & Safety Administration
PQL	Practical Quantitation Limit
PT	Proficiency Test
QA	Quality Assurance
QAO	Quality Assurance Officer
QAM	Quality Assurance Manual
QC	Quality Control
RPD	Relative Percent Difference
RSD	Relative Standard Deviation
SD	Sample Duplicate
SOP	Standard Operating Procedure

Attachment 2

Permit Requirements

SAMPLE LOCATION	SAMPLE TYPE	SCHEMATIC REFERENCE	PARAMETERS TESTED	MONITORING FREQUENCY
Influent	Continuous	1	Flow	Totalized Daily
Influent	24-hr composite (flow proportional)	1	Biochemical Oxygen Demand Total Suspended Solids	Daily
Effluent	24-hr composite (flow proportional)	2	Biochemical Oxygen Demand Total Suspended Solids Ammonia-Nitrogen Total Phosphorus	Daily
Effluent	Grab	2	Dissolved Oxygen pH Chlorine Residual [#]	Daily
Effluent	Grab	2	Fecal Coliform [#]	Twice weekly

Table 2 - Process Control Monitoring

SAMPLE LOCATION	SAMPLE TYPE	SCHEMATIC REFERENCE	PARAMETERS TESTED	MONITORING FREQUENCY
Aeration Tank	Outlet grab	4 & 5	Settleability (30 min.) Total Suspended Solids Volatile Solids	Daily
Aeration Tank	Contents in-place	4 & 5	Dissolved Oxygen	Continuous
Solids Concentrator	Product-grab	12 & 13	Percent solids	As needed
Solids Concentrator	Decant-grab	14	Biochemical Oxygen Demand Total Suspended Solids Ammonia-Nitrogen	As needed
Digester Contents	Grab	6 & 7	Settleability (30 min.) Percent solids Total Suspended Solids Volatile Suspended Solids	Daily
Clarifier	Grab	8 & 9	Blanket Depth Total Suspended Solids	Daily
Return Sludge	Grab	10 & 11	Total Suspended Solids	Daily
Filter Backwash	Grab	15	Biochemical Oxygen Demand Total Suspended Solids	As needed

Attachment 3

MDEP 49 Form

State of Maine
DEPARTMENT OF ENVIRONMENTAL PROTECTION
State House Station 17
Augusta, Maine 04333

MONTHLY REPORT OF OPERATION WASTEWATER TREATMENT FACILITIES

REPORT FOR: _____
(Facility)

MEPOES
Permit No. _____

FOR MONTH OF: Nov 2003

SIGNED BY: _____


MONTH OF: November 2003										Tertiary Treatment		WEATHER		DISINFECTION SYSTEM		DAILY TESTING (5week)				NUTRIENTS (EFFLUENT)				BOD 5				SUSPENDED SOLIDS						
FLOW DATA																																		
Day of week	DATE	Influent Flow Total	Totalizer Reading	Total Gallons Treated	Max. Flow (Instantaneous)	Min. Flow (Instantaneous)	Recycle Flow Rate (% of Influent)	Disinfectant Unit online	Time	Conditions (CLEAR, PARTLY CLOUDY, MOSTLY CLOUDY, OVERCAST, HAZE, FOG, DRIZZLE, RAIN, SLEET, HAIL, SNOW)	Temperature	Precipitation	UV Churns On Line	Fecal Coliform in final eff.	pH		TEMP.		SETTLABLE SOLIDS		NH ₄				TKN									
															Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent	Influent	Effluent		
		MG	Gallons	MG	MG	MG	%	%			°F	In	#	#/100 ml	SU	SU	°C	°C	ml/l	ml/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l	mg/l		
Sat	1	0893	11027000	0000	0000	0000	0%		1545	partly cloudy	60.0																							
Sun	2	0803	11027200	0000	0000	0000	0%		1330	rain	48.0	0.05																						
Mon	3	1220	11027300	0000	0000	0000	0%		0600	rain	46.0	0.29																						
Tue	4	1204	11027400	0000	0000	0000	0%		0800	overcast	41.0	0.24																						
Wed	5	1263	11027500	0551	1518	0000	0%	100%	0800	rain	46.0	0.01	1.34																					
Thu	6	1217	11120000	1023	1049	0988	0%	100%	0600	overcast	49.0	0.34	1.34	0	7.01	7.17	13.0	11.0	40.0	0.0														
Fri	7	1194	11223000	1252	2805	0000	0%	100%	0900	overcast	42.0		1.34		7.13	7.11	13.0	10.5	30.0	0.0														
Sat	8	1082	11381400	1768	1693	1634	0%	100%	0845	clear	40.0		1.34		7.14	7.12	12.5	10.0	14.0	0.0														
Sun	9	1144	11552700	1749	1843	1652	0%	100%	0810	clear	34.0		1.34																					
Mon	10	1176	11728000	1708	2222	0021	0%	100%	0900	clear	39.0		1.34	0	7.64	7.23	17.5	7.0	70.0	0.0														
Tue	11	1171	11896000	1852	2171	1572	0%	100%	0800	partly cloudy	38.0		1.34		7.21	7.20	11.5	12.0	0.3	0.0														
Wed	12	1281	12091000	1951	2115	1548	0%	100%	0900	overcast	40.0	0.12	1.34	0	7.13	7.17	12.0	7.0	4.0	0.0														
Thu	13	1387	12283200	1923	2033	1685	0%	100%	0900	rain	51.0	0.79	1.34	0	7.03	7.16	12.0	7.5	50.0	0.0														
Fri	14	1412	12475200	1897	2075	0004	0%	100%	0800	overcast	33.0	0.24	1.34		7.20	7.27	11.5	7.0	24.0	0.0														
Sat	15	1176	12694900	1972	2122	1670	0%	100%	1130	clear	41.0		1.34																					
Sun	16	0825	12903300	1958	2105	1755	0%	100%	1240	clear	40.0		1.34																					
Mon	17	1219	13060200	1989	2218	1691	0%	100%	0800	overcast	28.0		1.34	0	7.27	7.44	10.5	5.0	2.0	0.0														
Tue	18	1144	13257900	1856	2108	1678	0%	100%	0900	partly cloudy	35.0		1.34		7.11	7.33	11.0	5.0	0.4	0.0														
Wed	19	1187	13453500	1954	2109	1651	0%	100%	0900	overcast	45.0		1.34		7.13	7.30	11.5	5.5	1.5	0.0														
Thu	20	1325	13649000	1987	2164	1616	0%	100%	0750	rain	58.0	0.09	1.34	2	7.06	7.31	11.5	6.0	2.0	0.0														
Fri	21	1413	13844300	1984	2222	1698	0%	100%	0725	rain	45.0	1.27	1.34		7.13	7.29	11.0	7.0	23.0	0.0														
Sat	22	1095	14055400	1990	2254	1675	0%	100%	0900	clear	51.0	0.03	1.34																					
Sun	23	1145	14251000	2017	2195	1777	0%	100%	0820	clear	42.0		1.34																					
Mon	24	1211	14449000	1893	2182	1706	0%	100%	0900	partly cloudy	31.0		1.34	2	7.18	7.37	10.0	6.5	50.0	0.0														
Tue	25	1014	14547800	2002	2228	1700	0%	100%	0900	rain	44.0	0.09	1.34		7.14	7.30	11.0	7.0	15.0	0.0														
Wed	26	1265	14848400	2001	2159	1594	0%	100%	0900	partly cloudy	35.0		1.34		7.17	7.29	16.0	6.5	30.0	0.0														
Thu	27	1062	15082800	2029	2415	1718	0%	100%	0900	clear	51.0		1.34	0	7.21	7.42	11.0	7.0	18.0	0.0														
Fri	28	1377	15261000	2036	2356	1692	0%	100%	0945	overcast	43.0	0.03	1.34		7.11	7.36	17.0	6.5	38.0	0.0														
Sat	29	1428	15474000	2015	2361	1712	0%	100%	1000	partly cloudy	49.0	0.92	1.34																					
Sun	30	0900	15699700	2017	2126	1818	0%	100%	1245	partly cloudy	46.0		1.34																					
1			15959700																															
TOTAL		3,5223		TOTAL		4,7574		MAX/TOTAL		80.0	4.42	MAX		2	8.17	7.44	17.5	12.0	70.0	0.0	0.0	0.00	0.00	0.0	232.2	238.8	2.5	3.8	2.0	3.0	312.7	321.1	9.4	14.5
MAX		1428		MAXIMUM		2038		MAX DAILY PERMIT		1.27		MIN		26.0	0.01	MIN	0	7.01	7.11	10.0	5.0	0.3	0.0	0	203.7	202.9	1.6	2.5	1.3	2.0	304.0	313.7	8.2	6.5
MIN		0803		MINIMUM		0000		MO. AVG		43.0	0.35	MO. AVG		7.22	7.26	12.4	7.5	22.9	0.0	0.0	0.00	0.00	0	232.2	238.8	2.5	3.8	2.0	3.0	312.7	321.1	9.4	14.5	
AVG		1174		MO. AVG		1511		GEOMETRIC MEAN		1.0		MO. AVG PERMIT		15.0		WEEKLY AVG (highest week)		0	0.00	0.00	0	0	0	25	51									
WEEKLY AVG (highest week)		2017		WEEKLY AVG PERMIT		2442		PERCENT REMOVALS:		BOD: 98%		C8OD: 99%			SUS. SOLIDS: 95%																			

DEP 49


Revised 12/15/03

Attachment 4 Organizational Charts

Organizational Chart - Larger Facility



Organizational Chart - Smaller Facility



Attachment 5

Demonstration of Capability - Certification Statement

Date:			
Facility Name:			
Analyst(s):			
Matrix (circle):	Aqueous	Soil	Other:
Method # or SOP # :			
<p>We, the undersigned, CERTIFY that:</p> <ol style="list-style-type: none">1. The analyst(s) identified above, using the cited test method(s), which is in use at this facility for the analyses of samples, have met the Demonstration of Capability.2. The test method(s) was performed by the analyst(s) identified on this certification.3. A copy of the test method(s) and the laboratory-specific SOPs are available for all personnel on-site.4. The data associated with the demonstration of capability are true, accurate, complete, and self-explanatory(*).5. All raw data (including a copy of this certification form) necessary to reconstruct and validate these analyses have been retained at the facility, and that the associated information is well organized and available for review by authorized assessors.6. The analyst(s) identified above, have read, understood, and agreed to perform the applicable (approved method or SOP as specified by laboratory management) revision of the method and/or SOP.			

Manager's or Trainer's Name

Signature

Date

Analyst's Name

Signature

Date

*

True: Consistent with supporting data

Accurate: Based on good laboratory practices consistent with sound scientific principles/practices.

Complete: Includes the results of all supporting performance data.

Self-Explanatory: Data properly labeled and stored so that the results are clear and require no additional explanation.

Attachment 6

SUMMARY OF DOCUMENTATION REQUIREMENTS

REQUIREMENT	STOCK STANDARDS LOGBOOK	STOCK STANDARDS LABEL	WORKING STANDARDS LOGBOOK	WORKING STANDARDS LABEL
Date of Receipt	X	X		
Supplier	X			
Description or Name of Standard	X		X	X
Lot Number of Standard	X			
Receiver's Initials	X			
Date Opened		X		
Date of Expiration	X	X	X	X
Date of Preparation			X	X
Initials of Preparer			X	
Components of Standard			X	
Unique Working Identification Number			X	X
Preparation Procedure			X	
Final Concentration			X	

Example Label

Date Received:
 Date Opened:
 Date of Expiration:

[illegible]

RECEIPT LOGBOOK FOR REAGENTS, STANDARDS, MEDIA & SOLVENTS

[illegible]

REVIEWED BY:

DATE:

Facility Name

Corrective Action: Note in the “comments” column and notify the QAO or supervisor; document corrective actions taken and return to control.

[illegible]

Attachment 8

Balance Calibration

Remove the working weights from the desiccator. Do not touch the weights with your hands. These weights should be handled only with the plastic forceps provided in the weights' case or with plastic gloves or KIM wipes. The small weights (i.e., ≤ 2 g) are often difficult to pick up with the forceps so use extra care when handling these weights.

Clean the balance pan and surrounding areas.

Check balance level (if applicable to the balance). If the air bubble is not centered in the circle of the level indicator, relevel the balance using the leveling screws. If necessary, ask for assistance.

Verify that the balance draft shield is in place or that the balance is free of air currents which could cause balance drift. Balances that are not equipped with draft shields must be carefully monitored to ensure they are free of air currents when in use.

Verify balance zero. Readjust or retare if necessary using procedures appropriate for the balance.

All verification activities must be recorded in a balance logbook. Each logbook should contain the following information:

- Balance Serial #
- Location of the balance
- Balance Manufacturer's Tolerance – this indicates the \pm error of each reading
- Lowest weight to be weighed on the balance – this indicates the lowest weight that can be measured while still meeting the acceptance criteria for accuracy. Do not weigh anything on the balance below this weight. If lower weights need to be measured, another balance that meets the required calibration criteria at a lower weight range must be used.
- Date and initials of analyst
- True weights to be weighed and acceptance criteria for each weight
- Indication of pass/fail, comments and corrective actions

Using the weights appropriate (similar to the range being measured for the test), start by placing weight number one on the balance pan and recording its weight. Remove and be sure the weight returns to zero before proceeding with the remaining weights to be checked. Record all appropriate information in the logbook.

Based on the determined criteria, determine whether the measured weight passes or fails and indicate this in the logbook. If acceptance criteria are not met, do not continue to use the balance. Label the balance as "Out of Service" (initials and date) and immediately notify your manager. Document corrective actions taken, maintenance performed, and return to control in the logbook before resuming use of the balance.

Balance ID:
Location:
Manufacturer's Tolerance:

Manufacturer's Tolerance:

Lowest Weight to be weighed on this balance:

If acceptance criteria is not met, do not continue to use the balance. Label the balance as "Out of Service" (initials/date) and notify your manager. Document corrective actions taken and return to control before using balance. Document any maintenance performed in the "Comments" section of the balance calibration verification log.

[illegible]

Attachment 9

Thermometer Verification


Thermometers must be calibrated annually at each temperature range that will be used. Upon receiving a NIST-certified thermometer, or equivalent from the manufacturer or from a company, which has calibrated the thermometer record the correct values and label the thermometer with the appropriate corrections by applying a label. To check other thermometer readings versus a calibrated thermometer it is necessary to check for corrections at the temperatures that the thermometer was calibrated at. Both thermometers must be kept immersed to the immersion line and in close contact in a solid medium such as sand or vermiculite for higher temperature checks that exceed the boiling point of water, or a liquid medium such as water. It is preferable to have the thermometers suspended and not touching the edges of the container since different materials conduct heat differently. If you are checking complete immersion thermometers the complete thermometer must be submerged. Place the container with both thermometers submerged to the immersion line and suspended in a medium into the refrigerator to check at 4⁰ C, into the BOD incubator to check at 20⁰ C, into the water bath to check at 44.5⁰ C into the oven to check at 103⁰ C. Allow the thermometers and medium time to reach the appropriate temperature. Once the readings seem stable take readings on both thermometers and record. Allow the thermometers to remain at that temperature for another hour and record readings again to check for stability of readings. If the initial and final readings match, determine the difference if any from the calibrated thermometer and attach a label which indicates how much to adjust readings at each temperature checked. The amount of adjustment might vary from the low temperature range to the high temperature range. For instance at 4⁰ C one might add 1⁰ C whereas at 103⁰ C one might subtract 0.5⁰ C. Variation is dependent on the expansion of the metal or liquid component of the thermometer.

FACILITY NAME – ADJUSTABLE PIPET CALIBRATION LOGBOOK

Pipet Range: Min. Mid. Max.



Attachment 11

Example Glassware & Meniscus Reading



Attachment 12

Example Calibration Curves



Attachment 13

Chain-of-Custody

[illegible]

Attachment 14

Example MDL


MDL-BOD99.XLS

			MDL For BOD				
			06/18/1999				
	Results	X-X	(x-x)		Number of replicates	Degrees of freedom (n-1)	t, 0.99
1	13.44	0.80	0.6346778				
2	12.96	0.32	0.1002778		7	6	3.143
3	13.41	0.77	0.5877778		8	7	2.998
4	13.14	0.50	0.2466778		9	8	2.896
5	13.29	0.65	0.4181778		10	9	2.821
6	12.30	-0.34	0.1178778		11	10	2.764
7	12.69	0.05	0.0021778		16	15	2.602
8	10.17	-2.47	6.1173778		21	20	2.528
9	12.39	-0.25	0.0641778		26	25	2.485
10					31	30	2.457
11					61	60	2.39
					0	0	2.326
Average:	12.64						
Sum:			8.2892				
n-1:			8				
sum/n-1:			1.03615				
standard deviation:			1.01791				
MDL:			2.9				


Attachment 15

Example Control Charts


TEST IN CONTROL




A TREND



SHIFT



RANDOM ERROR



Attachment 16

FACILITY NAME
MAINTENANCE LOG

DATE	INIT.	INSTRUMENT	PROBLEM OR PREVENTATIVE?	MAINTENANCE	DATE RETURN TO CONTROL

PLEASE EXPLAIN IN DETAIL WHAT THE PROBLEM IS OR IF IT IS ROUTINE MAINTENANCE. DESCRIBE IN DETAIL THE MAINTENANCE PERFORMED.

Attachment 17
Example Benchsheets

Facility Name: _____

Total Suspended Solids Analysis (mg/L)

sample collection date: _____ time: _____ by: _____

sample location: _____

analysis run date: _____ time: _____ by: _____

preservative used: _____

sample volume (mL): _____

method used: _____

	Sample #1	Sample #2	Sample #3
weight of filter + dried solids (g)			
subtract tare weight of filter (g)			
weight of suspended solids (g)			
x 1,000 mg/g			
divided by sample volume (mL)			
x 1,000 mL/L			

Comments:

TOTAL SUSPENDED SOLIDS (TSS)

Initials: _____

Sample Date: _____

Time: _____

Analysis Date: _____

Time: _____

Oven Temperature: In: _____

Out: _____

Drying Times: Initial: _____

Final: _____

Sample Type	Influent		Effluent	
	No. 1	No. 2	No. 1	No. 2
Sample Volume (mL)				
Initial weight				
Final weight				
g of Solids				
Results (mg/L)				

Calculations:

$$\text{mg TSS / L} = \frac{(\text{weight of filter + dried residue (g)} - \text{weight of filter (g)}) \times 1000}{\text{L of sample}}$$

TOTAL SUSPENDED SOLIDS (TSS)

Initials: _____

Sample Date: _____

Time: _____

Analysis Date: _____

Time: _____

Oven Temperature: In: _____

Out: _____

Drying Times: Initial: _____

Final: _____

Sample Type	Influent		Effluent	
	No. 1	No. 2	No. 1	No. 2
Sample Volume (mL)				
Initial weight				
Final weight				
g of Solids				
Results (mg/L)				

Calculations:

$$\text{mg TSS / L} = \frac{(\text{weight of filter + dried residue (g)} - \text{weight of filter (g)}) \times 1000}{\text{L of sample}}$$

**pH QUALITY CONTROL
CALIBRATION RECORD**

Month of _____

Date	Cal. Std. 4.00	Cal. Std. 10.00	Check 7.00	Reading	Slope	Sample Temp.	Initials	Time
1.								
2.								
3.								
4.								
5.								
6.								
7.								
8.								
9.								
10.								
11.								
12.								
13.								
14.								
15.								
16.								
17.								
18.								
19.								
20.								
21.								
22.								
23.								
24.								
25.								
26.								
27.								
28.								
29.								
30.								
31.								

APPENDIX F

BOD/CBOD BENCH SHEET

Sample Date: _____ Analysis Date: _____ Read Date: _____
 Time: _____ Time: _____ Time: _____
 Initials: _____ Initials: _____ Initials: _____

Incubator Temperature: Day 1: _____ 4: _____
 2: _____ 5: _____
 3: _____

Dechlorination: _____

Sample Type	Blank	Seed Blank	Infl. BOD No. 1	Infl. BOD No. 2	Effl. BOD No. 1	Effl. BOD No. 2	G&G
Bottle #							
mL Sample							
Sample Temp							
Init. DO							
Final DO							
Depletion							
Seed Correction							
BOD mg/L (CBOD) mg/L							

Calculations:

$$\text{BOD of SEED} = \text{DO DEPLETION} \times \frac{\text{Volume of bottle}}{\text{mL of seed added to bottle}}$$

$$\text{Seed Correction} = \text{BO of Seed} \times \frac{\text{volume of seed added to dilution bottle}}{\text{volume of bottle}}$$

$$\text{BOD of Sample mg / L} = \frac{(\text{DO Depletion} - \text{Seed Correction}) \times \text{volume of bottle}}{\text{mL of sample}}$$

APPENDIX C

Sample Bench Sheets

MPN Test Data Sheet

Date: _____ Test Date: _____
 Sample Number: _____ Selected Series: _____
 Location: _____ MPN/100 mL: _____
 Sampler: _____ Analyst: _____

Volume mL	Tube no.	Presumptive Test		Confirmed Test	comments
		24 hr	48 hr	24 hr	
	1a				
	1b				
	1c				
	1d				
	1e				
	2a				
	2b				
	2c				
	2d				
	2e				
	3a				
	3b				
	3c				
	3d				
	3e				
	4a				
	4b				
	4c				
	4d				
	4e				
	5a				
	5b				
	5c				
	5d				
	5e				

Membrane Filter Test Sheet

Date: _____ Sample Number: _____

Location: _____ Sampler: _____

Test Date: _____ Selected filter: _____

Colonies/100 mL: _____ Analyst: _____

Dish Number	Sample Volume mL	Colony Count

Quality Control

Fecal Coliform MFC Broth Preparation

Name of Media: _____ Lot #: _____

Expiration Date: _____

Date of preparation: _____

Amount weighed: _____ gm Vol. Prepared: _____ mL

Sterilization by: _____

Prepared by: _____

Sterility Check by: _____

Date: _____

Number of Colonies: _____

Growth Check by : _____

Date: _____

Number of Colonies: _____

APPENDIX C

Sample Bench Sheet

Phosphate Analysis

Sample collection Date: _____

Time: _____

By: _____

Sample preserved? yes no

Preservative: _____

Analysis run Date: _____

Time: _____

By: _____

Sample Type	Initial Volume	Final Volume	Absorbance	Conc.	Corrected Conc.

Attachment 18

FACILITY NAME– CORRECTIVE ACTION REPORT

Problem Identification (Person discovering problem) Name:			Date:
Affected Samples:			
LCS Failure Blank Contamination Poor Precision	Prep Error Hold Time Missed Linearity	Transcription Error Detection Limit Calculation Error	Sample Contamination Other Matrix Spike Failure
Details:			
Corrective Action Plan		Name:	Date:
Details of Corrective Action Plan – Short Term and Long Term (if applicable):			
Review & Comments			
Chief Operator/Superintendent Approval:			Date:
Root Cause Investigation (To be completed by handling QA Activities)			
Lack of Organization	Lack of Training	Circumstances Beyond Control	Undetermined
Lack of Resources	Lack of Time	Lack of Top Management Support	Further Monitoring Needed
Lack of Experience	Lack of Discipline	Lack of Communication	Isolated Event
QA Approval:		Date:	